

2x
B&W
i-Type
Film

2x
Color
i-Type
Film

i-Type Film Double Pack

We love Polaroid cameras, and Polaroid cameras love film. So naturally, we want you to have as much film as possible at all times. And... voila. This i-Type Film Double Pack offers two new packs of film in a single box, individually foil-wrapped so they stay fresh until you're ready to shoot, and for a lower price than two single packs. Sounds like a pretty sweet deal to us.



2 x 8 Instant Photos

- [1] Film speed may vary, allow for +/- 1/2 stops
- [2] Do not freeze the film

Format
Image Area
Finish
HS or HTS code
PRD #
EAN #
Battery report (UN38.3)
Warranty info

- ☒ Classic white frame
- ☀ ASA 640^[1]
- ☒ Photos develop in 5-10 mins
- ☀ Best stored refrigerated^[2]

3.5" x 4.25" (8.8 cm x 10.8 cm)
3.1" x 3.1" (7.9 cm x 7.9 cm)
Glossy
37012000
004838
9120066088765
No Battery- no UN38.3
polaroidoriginals.com/warranty

2 x 8 Instant Photos

- [1] Film speed may vary, allow for +/- 1/2 stops
- [2] Do not freeze the film

Format
Image Area
Finish
HS or HTS code
PRD #
EAN #
Battery report (UN38.3)
Warranty info

- ☒ Classic white frame
- ☀ ASA 640^[1]
- ☒ Photos develop in 10-15 mins
- ☀ Best stored refrigerated^[2]

3.5" x 4.25" (8.8 cm x 10.8 cm)
3.1" x 3.1" (7.9 cm x 7.9 cm)
Glossy
37012000
004836
9120066088741
No Battery- no UN38.3
polaroidoriginals.com/warranty

Store chilled, shoot warm

Temperature affects how the film works. Keep it stored cold in the fridge, but never freeze it. Ideally you should let it adjust to room temperature before you use it. That's around 55-82°F (13-28°C). When it's cold out, keep your photos warm in a pocket close to your body while they develop. Or if it's a hot day, make sure they stay cool.

Shoot with the light

The more light in your shot, the better your photo will turn out. Instant film loves light, especially natural light. Use the flash for all your indoor photos. For best results we also recommend using the flash for outdoor shots, unless it's a bright sunny day.

Develop in the dark

All photos appear blank at first. They're most sensitive during this time, so don't bend or shake them. Shield them from the light, and place them face down as they develop. Keep B&W photos shielded from light for about 1 minute, and color film for about 6 minutes.

Care for your camera

Your camera has a set of rollers inside the film door. Each photo passes through these rollers as it's made, so it's important to make sure that they stay clean. If the rollers get visibly dirty then gently wipe them down with a soft, damp cloth.

For use with:



Polaroid i-Type Impossible i-Type Impossible Instant Lab

Does not work with:



Vintage Polaroid cameras

Have a problem, or a question you need answered?

USA/Canada
usa@polaroidoriginals.com
1-212-219-3254

Contact our Customer Support Team

EU/Rest of World
service@polaroidoriginals.com
00800 5770 1500

or visit polaroidoriginals.com/help

Polaroid, the Polaroid Classic Border Logo and Polaroid Originals Design are trademarks of PLR IP Holdings, LLC, used under license.