


USER'S MANUAL
7PCS BAR TABLE SET
HW68237 -13 -23 -33

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP!

FLOOR AREA
2MX2M



ASSEMBLED BY 2ADULT

Follow Costway




Contact Us!

Do NOT return this item.


Contact our friendly customer service department for help first.















Before You Start



- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.





Component List



 <p>① Bar table top with dowels x1 pc</p>	 <p>② Bar table top with the holes x1 pc</p>	 <p>③ Table leg x2 pcs</p>
 <p>④ Table stretcher x2 pcs</p>	 <p>⑤ Table Apron 1 x2 pcs</p>	 <p>⑥ Table Apron 2 x2 pcs</p>
 <p>⑦ Apron connector x2 pcs</p>	 <p>⑧ Left Chair leg x6 pcs</p>	 <p>⑨ Right Chair leg x6 pcs</p>
 <p>⑩ Cross bar x6 pcs</p>	 <p>⑪ Chair seat x6 pcs</p>	 <p>⑫ Front-Chair apron x6 pcs</p>
 <p>⑬ Chair back x6 pcs</p>	 <p>⑭ Parasol cap x1 pc</p>	

 <p>A M4x 15mm Screw x14 pcs</p>	 <p>B M4x 40mm Screw x54 pcs</p>	 <p>C M6 x 15mm Bolt x12 pcs</p>
 <p>D M6 x 20mm Bolt x72 pcs</p>	 <p>E M6 x 25mm Bolt x12 pcs</p>	 <p>F M6x18x2 Washer x12 pcs</p>
 <p>G Allen key x2 pcs</p>		



STEP 1: X6





STEP 2: X6



STEP 3: X6





STEP 4: X6




BAR STOOL


STEP 5: X2




STEP 10



STEP 11




STEP 12




BAR TABLE


STEP 13



STEP 14



STEP 15



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since Long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.

