

USER MANUAL

Life is a journey. Enjoy the ride

(4G)



FAQ


Q: How to connect the Junsun rear view camera?

A: 1. Red cable ② is connected to the backup light "+"
2. Black cable ① is connected to the backup light "-"
3. The reversing detection cable ④ (Brown color) is connected to the red cable ③ which extending from the video input cable. Please click on the image below to connect or scan the QR code below to view the connection video.



Q: How to connect with Junsun radio after confirming the support of original rear camera before purchase?

A: If you have the yellow connector in figure 1 inside your cable package, please connect it according to figure 2.



Q: Left side button touch unresponsive?

A: Please refer to the following video to learn (with QR code)




Q: The buttons on the left side of the screen don't light up?

A: Please check according to the following steps


1. The left side button light comes on with the headlight of the car, make sure whether the headlight is on or not;
2. Check whether the ILL small light wire is loose;
3. Connect the ILL light cable to the ACC cable to see if it is on;

Please note that if your machine model is DW, please make sure whether there is "Color" apk file in the machine, if not, you need to contact Junsun customer service to resend and install this file and the left side button will work again.



Q: No canbus steering wheel buttons do not work in production?

A: You need to learn the steering wheel button, please refer to the following picture or video to learn.



Q: How to use wireless carplay/Android Auto function?

A: Please check the video for connection steps.

Carplay




Android Auto




Q: The original car has an amplifier, but there is no sound after connecting the Junsun radio?

A: 1. No RCA cable, please connect the ACC of the main cable with AMP. (Refer to the following figure)




2. With RCA cable, please connect the AMP of RCA cable with the main cable. (Refer to the picture below)



Q: Is it possible to change the language?

A: Junsun radio supports most of the languages, please refer to the following picture to see the steps to change the language.

Please note that after adding the desired language on the last page, please long press on this language to move to the top.



If none of the above solves the problem you encounter, please contact us through the Junsun Store online customer service.

We will be happy to serve you.

Your satisfaction is our service purpose.

Junsun

Operating Instructions

Foreword: We are very happy that you have chosen this car navigation audio and video product. This manual will systematically introduce the basic functions, usage skills, and precautions of the car. To help new users quickly get to know the product, please read carefully before using. Thank you!

Table of Contents

The first module: Basic Knowledge

- 1.1 Boot and Shutdown Instructions
- 1.2 Main Interface and Application Interface
- 1.3 Drop-Down Menu and Status Bar
- 1.4 Wallpaper Replacement

The second module: The Main Function

2.1 Navigation Function

- 2.1.1 Use of Maps
- 2.1.2 Map Offline Data Copy and APK Installation
- 2.1.3 Selection of Navigation Path

2.2 Radio Function

2.3 Bluetooth Function

- 2.3.1 Paired Devices
- 2.3.2 Bluetooth Music
- 2.3.3 Bluetooth Address Book

2.4 Music

- 2.5 Video
- 2.6 Equalizer (EQ)
- 2.7 AV IN
- 2.8 Third-Party Application - CarLetter

The third module: Settings

- 3.1 Internet and Networks
- 3.2 Sound Settings
 - 3.2.1 Reversing Mute
 - 3.2.2 Navigation Channel
 - 3.2.3 Navigation Volume
 - 3.2.4 Device Ringtone
- 3.3 Date and Time
- 3.4 Switching Input Method
- 3.5 Steering Wheel Learning
- 3.6 Method for Models with CAN Protocol

Common Settings


- 4.1 Split Screen
- 4.2 Interface Annotation
- 4.3 Rear Camera Connection
- 4.4 Button Light Settings






Device Ports

Basic Knowledge

1.1 Boot and Shutdown Instructions

boot	Plug in the car key,turn on the ACC power,the device will automatically boot,display the boot LOGO animation
and shutd own	After removing the car key and turning off the ACC power,the device will automatically shut down





	Power	Power on state.Long press system off screen Short press,mute
	Main interface	Press to return to the main interface
	return	Press to return to the previous nterface and exit the current source
	Volume plus	Press volume up
	Volume reduction	Decrease the volume

1.2 Main Interface and Application Interface


1.This device has a multi-page screen, and you can slide to the left or right to switch between the pages.

2.Click the application icon on the main interface to enter the application interface.




1.3 Drop-Down Menu and Status Bar

The car status bar and drop-down menu functions include:



1.4 Wallpaper Replacement

Navigate to Car Settings > Display > Wallpaper, and select the wallpaper source based on your personal preferences.




The second module:the main function

2.1 Navigation Function

2.1.1 Use of Maps


To access the navigation function, click the navigation icon on the main interface or the application interface.



2.1.2 Copying and Installing Maps

1.Copy the map package to an SD card or USB flash drive, and connect the drive to the car's infotainment system using a USB cable.

2.Click to enter the file management application interface. On the left side of the file manager, you can see the path of the connected USB flash drive.





3.Insert the USB flash drive and check the map data package. Click on the "Copy" button in the top right corner. Then switch to the "Local" directory and click on the "Paste" button in the top right corner. The copying process is expected to take 10 minutes. After the copying is completed, click on the map APK to install it.

2.1.3 Selection of Navigation Path


After copying the offline map data and installing the map APK, you can associate the navigation icons on the main interface by following these steps:

Car Settings -> General Settings -> Set Associated Navigation Program



2.2 Radio Function.

Click on the radio function on the main interface or application interface to enter the radio interface.



	Search station		DSP settings
	long-distance switching		Voice
	Low frequency sweep		Low frequency stepping
	Switching FM1/FM2		High frequency stepping
	High frequency sweep		
		Long press to save	


2.3 Bluetooth Function

To access the Bluetooth interface, click on the Bluetooth function.

2.3.1 Paired Devices


1. When you are not paired with a device, you can only access the settings and search interface.

2. Pairing Interface: Click 🔍 to find nearby devices, select the device to be paired. The phone will display a PIN code box. Enter the PIN code. The 🟡 icon indicates that the connection was successful.




2.3.2 Bluetooth Music

Click the ⚙️ icon to enter the music player interface. After connecting with a phone, you can operate the "Play and Pause" and "Previous/Next" functions.




Note: Using the Bluetooth music function, the music player of some mobile phones needs to open the music page from the mobile phone first

2.3.3 Bluetooth Address Book

1.In the Bluetooth interface, click  to enter the address book interface.


2.Download Steps: Select Phone/SIM and click the "Download" button to confirm the synchronization request for the address book.



3.Find a Contact: After synchronizing the address book, click the corresponding phone/SIM button, and a search box will pop up.

2.4 Music Function:

Select the playback path at the top of the interface: [Playlist], [SD Card], [U Disk], [Local].



2.5 Video Function:

Click the video function to enter the video playback interface. The video player supports the following formats: MP4, AVI, WMV, MOV, MKV, MPEG, RMVB, etc. Select the playback path at the bottom of the interface: [Playlist], [SD card], [USB drive], [Local].



2.6 Equalizer (EQ)

2.6.1 There are two ways to enter the EQ interface:

In the application interface, click to enter the equalizer setting. Click on the radio and music interface to enter the equalizer setting interface.

2.6.2 Classification: Equalizer and Sound Field Settings

1. Equalizer settings with 9 sound effects to choose from.


2. Sound field settings allow users to freely adjust bass and loudness contrast, as well as adjust the volume of the front left, front right, rear left, and rear right directions.



2.7 AV Input Function

Access the AV IN interface:

- 1.If no video input signal is connected, the AV IN interface will show "AV IN".
- 2.When a video input signal is detected, the AV interface will display the video screen. Press the D key to return to the previous screen and the key to return to the main screen. The screen will automatically hide after a timeout.




2.8 Third-Party Application - CarLetter

When connecting for the first time, ensure that the Bluetooth on your phone is enabled to pair with the car's Bluetooth.

Once successfully paired, enable Wi-Fi on the car's radio and connect your phone to the radio's Wi-Fi network. Once the Wi-Fi connection is established, CarPlay/AndroidAuto will automatically connect.

Please note that if the initial connection is unsuccessful, try restarting both devices and disconnecting any previous connection before attempting to connect again.



The Third module: about settings

3.1 Networks and the Internet

3.1.1 WiFi

There are two ways to turn on and off WiFi:


1. Drop-down menu WLAN function: Long press: Enter the WLAN setting interface.

2. Settings→Network and Internet→WLAN

3.1.2 4G Network

To turn on 4G

1. Pull down menu Mobile data function. Short press: Switch off/on.



3.2 Sound

The sound settings are mainly about four common functions: reversing mute, navigation channel, navigation volume and device ringtone.

3.2.1 Reversing mute: When checked, any mode reverses, the car has no sound output; when unchecked, there is sound output.

3.2.2 Navigation channel:Prerequisites:Bind navigation, (Navigation software interface select map APK)

- 1.Front left and front right:When navigating,it is not a system sound source, such as radio/AUX/DVD/TV/external Bluetooth mode,navigation only outputs from the front left and front right,and the left and right rear keeps the sound of the current source;
- 2.All:When navigating,all four channels have navigation sounds.

3.2.3 Navigation volume


- 1.Navigation:slide the progress bar,adjust the volume of the navigation,and then navigate after setting.
- 2.background music:slide the progress bar,adjust the current source sound size, adjust the size,reduce the current source sound when navigating;adjust to 0,insert the video when navigating,(the current source has no sound output when navigating the broadcast);The source sound is raised.

3.2.4 Device ringtone:music played when the car calls.

3.3 Date and time

The device automatically calibrates the current time,manually setting the date,time, timezone,and format using the time and time zone provided by the network.


Settings →System →Date and time,you can set the time zone and time format as needed



3.4 Language Settings

To access language settings, go to Settings → System → Language and input → Language.

Drag the desired language to the top or add other languages.




3.5 Learning the steering wheel

Car settings - General - SWC type - Learning type. Then click Enter SWC setting interface to enter the learning interface.

The square control interface is only available for models without CAN protocol. Learning Procedure


1. Click the button you want to learn.
2. Press the corresponding button on the steering wheel of the vehicle. If learning is successful, the buttons on the square control interface will change color accordingly.
3. Repeat steps 2 and 3 until all buttons on the steering wheel are set.
4. Click [End] to end the controller setup process.



Note: If you want to relearn the steering wheel button,click [Start] and then click [Clear], then repeat steps 1, 2, and 3.

3.6 Method for models with CAN protocol


Car Settings-Factory-password(000000)--CarType Setting choose the corresponding information and click OK to save.




4.1 Split Screen

Click pop up multiple pages,drag the pages you need to split the screen to the left and right.


Please note that not all applications support split-screen, and it is normal for some applications not to support it.



4.2 Interface annotation



4.3 Rear camera connection



4.4 Button light settings


Car Settings-Display--illumination color

Model 1

Open LED Animation:Automatic color change

Model 2

Close LED Animation:Click to switch colors manually



At this point.the description is over.thanks for reading.



Shenzhen Junsun E-Commerce Co., Ltd.



Junsun888@163.com



www.junsun-china.com



Floor 6 West, Building No. 9 Area A,
Tianliao Industrial Area, Xueyuan Road,
Nanshan, Shenzhen

