



ONE-YEAR WARRANTY

This Vanity Planet product is warranted to be free of manufacturer's defects in materials or workmanship for one year from the date of purchase. Damage or wear resulting from an accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair are not covered under this warranty.

Should this product require warranty service (or replacement at our discretion) please contact client service to obtain a Return Merchandise Authorization number (RMA) and return instructions; proof of purchase is required. Products returned without a Vanity Planet generated RMA number will not be accepted and the sender will not receive a refund, replacement, or repaired product.

VANITYPLANET.COM
INFO@VANITYPLANET.COM
1.888.870.2132

There are no express warranties except as listed above. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

Please do not return this product to the retailer. Contact us directly for warranty service or repair, thank you.

SUBSCRIBE & SAVE PROGRAM

REPLACEMENT HEAD PROGRAM

To keep your Vanity Planet Spin for Perfect Skin spinning in top condition, dermatologists recommend replacing your brush heads every two to three months. Our Subscribe & Save program will ensure that you receive the optimal cleansing and exfoliating results without a second thought.

New brushes are available at vanityplanet.com

Subscribe to our convenient refill program and save 25% on every refill order.



HEY THERE GOOD LOOKIN'

In this box, you'll find a top notch product waiting patiently for your attention. Let's be honest, you know an awesome buy when you see one, so thanks for choosing our goods to add to your stellar beauty routine.

The way we see it, we're here to help you enhance your unfair level of attractiveness. Why? Because we think confidence looks best on everyone.

XOXO
VANITY PLANET

**DON'T FORGET TO SHOW OFF YOUR GOODS BY USING THE
#MYVP AND #VPBEAUTY HASHTAGS.**

YOUR SPIN FOR PERFECT SKIN

The Vanity Planet Spin for Perfect Skin is a complete system that is safe for use in or out of the shower or bath. Inside this box you will find everything you need for an enhanced cleansing and exfoliating experience. The Cleansing and Exfoliating Brush attachments gently, yet effectively cleanse the delicate skin on your face and neck while the Pumice Stone and Body Brush attachments allow you to pamper and polish your entire body.

An essential tool for use in your daily skin care ritual, the Spin for Perfect Skin is a professional-caliber device that uses a gentle, rotating, micro-massage action to treat your skin to a luxurious clean. The Spin for Perfect Skin gently clears pores without harsh abrasion or chemicals. As a result, your skin can better absorb the products you use. Results include a reduction in the appearance of pores, fine lines & wrinkles by improving skin tone.



CLEANSING BRUSH

The Cleansing Brush is made of ultra-soft bristles that are specially designed for your tender and sensitive facial skin. For best results, always dampen your face and the brush prior to use.



EXFOLIATING BRUSH

The hygienic, quick-drying bristles of the Exfoliating Brush are specially designed to lift away debris. We recommend cleansing your face before exfoliating for optimum usage.



PUMICE STONE

The Pumice Stone is designed to effectively remove calluses and dead skin from your elbows, feet, and knees. Not intended for use on delicate facial skin.



BODY BRUSH

The Body Brush extends the benefits of deep cleaning to your entire body. The large brush head is the perfect size for exfoliating your arms, back, and legs.

USING YOUR SPIN FOR PERFECT SKIN

- Before using the Spin for Perfect Skin, remove any existing eye makeup.
- Wet your skin and the brush head with warm water.
- Apply cleanser to your skin or directly to the brush head.
- Push the on/off button to turn on the Spin for Perfect Skin.
- Gently move the brush head in small circular motions around the area you are cleansing.
- Push the on/off button again when finished to turn off the Spin for Perfect Skin.

Note: Keep the brush head flush to your skin. Pressing too hard will impede the motion of the brush and reduce its effectiveness.

INSERTING THE BATTERIES

For maximum run time, we recommend using alkaline batteries. Use one hand to hold the device and the other hand to hold the battery cap. With your thumb at the "open" mark, pull the cap off. Insert 4 AA batteries in alignment with the polarity symbols (+ / -) indicated on the unit. Then replace the battery cap and you're ready to spin.

IMPORTANT SAFEGUARDS & WARNINGS

If you are under a doctor's care for any skin condition or if you think you may have a skin condition, please consult your physician before using the Vanity Planet Spin for Perfect Skin. To ensure that you experience the full range of benefits from the Vanity Planet Spin for Perfect Skin we recommend the following:

- Do not share brush heads with anyone.
- Use with a gentle daily cleanser designed for the face.
- Do not use jagged exfoliating particles, such as shells, with the Spin for Perfect Skin.
- If you would like to use with an exfoliating product, use one that contains soft, rounded particles.
- Using your Vanity Planet Spin for Perfect Skin to remove makeup may stain the bristles of the brush head; if discoloration occurs, clean the brush head with soap and water.
- Change your brush heads every two to three months.

CARING FOR YOUR SPIN FOR PERFECT SKIN

To keep your Spin for Perfect Skin in optimum condition, do not use abrasive cleaners or chemicals to clean any part of the unit. The handle is sealed and fully waterproof. However, you should not submerge any part of the Vanity Planet Spin for Perfect Skin under water.

CLEANING THE HANDLE

- To remove any residue or buildup, clean the handle at least once a week by removing the brush head and washing the device thoroughly with soapy water.
- Never attempt to open the brush handle for any reason.

CLEANING THE BRUSH HEADS

- Rinse brush heads thoroughly after every use.
- Dermatologists recommend replacing brush heads every three months with regular use.