

Congratulations on your purchase of a high-quality Insignia product. Your Insignia NS-SPBTP1-W Bluetooth plug-in wall speaker represents the state-of-the-art in speaker and Bluetooth design and is designed for reliable and trouble-free performance.

PACKAGE CONTENTS


- Bluetooth plug-in wall speaker
- *Quick Setup Guide*

FIND YOUR USER GUIDE ONLINE!

We are going green so a copy of your *User Guide* is not provided in the box but is available online. Go to www.insigniaproducts.com, then click **Support & Service**. Enter your model number in the box under **Manual, Firmware, Drivers & Product Information**, then click ►.

FEATURES


- Bluetooth connectability
- Built-in power adapter
- Built-in rechargeable battery




#	ITEM	DESCRIPTION
1	(Power/Pair) button	<ul style="list-style-type: none"> • Press and hold for three seconds to turn this system on. Press and release to turn it off. • Press and hold for two seconds to put this system into pairing mode.
2	Volume +/- buttons	Press to increase or decrease the volume level of playback.
3	Battery/pairing indicator	<ul style="list-style-type: none"> • Indicates the battery charging status. • Indicates the pairing states.
4	AC power plugs (foldable)	Fold down, then plug into a wall outlet to charge your speaker.
5	AUX IN jack	Plug an external audio device into this jack to hear the playback from this speaker.
6	USB charge port	Connect an external device to this port to charge it.

CHARGING THE BATTERY

- This system has a built-in rechargeable battery. To charge, fold down the AC power plug as shown below, then gently insert it into a wall outlet.




- The battery indicator indicates the charging state.



MODE	CHARGING	FULLY CHARGED
Standby	Solid red	Off
Power on (not connected)	Lights alternately red and purple	Blinking blue
Bluetooth mode	Solid purple	Solid blue
AUX IN mode	Lights alternately red and purple	Blinking blue

USING YOUR BLUETOOTH SPEAKER



Top view

- 1 Press and hold the (power/pair) button for three seconds to turn on your speaker.
- 2 Press and hold the (power/pair) button for two seconds to enter pairing mode. The pair indicator light flashes blue rapidly.
- 3 Open the Bluetooth settings on your Bluetooth-enabled device. After this system is recognized, **NS-SPBTP1** appears in the list of Bluetooth devices.
- 4 Select **NS-SPBTP1** to pair with your device. The pair indicator light turns solid after this system is successfully connected. You can use your paired device to control playback.


Notes:

- On most devices, no password is needed to pair, however, if a password is requested, the default password is **0000**.
- Before playing back using Bluetooth, make sure that the audio cable has been removed from the **AUX IN** jack of this system.
- You can change the playback volume by either pressing the **VOLUME+** or **-** buttons on the top of your speaker, or changing the volume on your paired device. For maximum volume, turn both to maximum.

CONNECTING TWO BLUETOOTH DEVICES

- 1 Press and hold the (power/pair) button for two seconds to disconnect the current Bluetooth connection and enter pairing mode, then follow steps 3 and 4 above to establish a Bluetooth connection with another device.
- 2 On the initial Bluetooth device, select **NS-SPBTP1** in the list of available Bluetooth devices to resume the connection. Now, both of the two Bluetooth devices are simultaneously connected to this speaker.
- 3 Start playback of one paired device to stream music to this system. If you want to play from the other paired device, pause the current playback and start playback on the other paired device.

PLAYBACK USING AUX IN




Right view

- Connect a 3.5 mm cable into your audio device and the **AUX IN** jack on your speaker. The audio defaults to your audio device when it is playing and the volume is turned up. If your audio device isn't playing sound, the speaker defaults back to any Bluetooth device that it is paired to.

Note: When playing music via audio cable, it is suggested that you pause the Bluetooth sound source paired to your speaker or disconnect the Bluetooth device.

CHARGING AN EXTERNAL DEVICE



Right view

- Use the USB charge port to charge external devices, including most mobile phones, tablets, and wireless headsets. You can use the power cable that came with the device. Charging is available when this system is connected to a wall outlet.

Note: The maximum output current of the USB port is 1000mA when the system is idle. The output current is 500mA when this system is playing music.

TROUBLESHOOTING

For troubleshooting information, see your online *User Guide* at www.insigniaproducts.com.

SPECIFICATIONS

- Dimensions (H×W×D): 3.7 × 3.7 × 1.4 in (9.5 × 9.5 × 3.5 cm)
- For additional specification information, see your online *User Guide* at www.insigniaproducts.com.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)
www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies. Registered in some countries. Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A. ©2014 Best Buy. All rights reserved. Made in China