

# Flashlight

## Quick Setup Guide

BE-BFL100AM

**BEST BUY**  
**essentials**<sup>™</sup>


Before using your new product, please read these instructions to prevent any damage.

### Package contents

- LED Flashlight
- Carrying case
- Carrying strap
- Best Buy essentials AAA batteries (3)
- *Quick Setup Guide*

### Features

- 350 lumen output makes your flashlight ideal for general indoor and outdoor use.
- Premium metal construction provides durability and dependability.
- IPX4 rating provides protection in dusty and damp environments (not waterproof).
- Three brightness levels plus a strobe (flashing) mode provide a wide range of lighting options.
- Carrying case and strap makes it easy to carry and keep track of your flashlight.



### Installing the batteries

- 1 Turn the end cap on the bottom of your flashlight counterclockwise to open the battery compartment, then remove the battery holder.
- 2 Insert three AAA batteries (included) into the battery holder. Make sure that you insert the batteries so that the + and - match the graphic to the right.
- 3 Insert the battery holder into the flashlight body with the spring-loaded point facing the front of the flashlight. Replace the end cap, then turn the cap clockwise to tighten.


#### Notes:

- Do not mix batteries of different types because the batteries might leak.
- Do not mix old and new batteries.
- Remove batteries when the charge is depleted.
- If your flashlight is not going to be used for an extended period of time, remove the batteries.

**Tip:** Use non-rechargeable lithium or premium rechargeable batteries to extend the run time of your flashlight.

### Using your flashlight

- 1 Press the On/Off button.
- 2 Quickly press and release the Mode (\*<sup>⌘</sup>) button one or more times to select a brightness level (high, medium, or low), or press and hold the button for about 1.5 seconds to select strobe mode.  
**Note:** To exit strobe mode, press and hold the Mode (\*<sup>⌘</sup>) button again. Your flashlight returns to the last brightness level you selected.
- 3 To turn off your flashlight, press the On/Off button.



## Troubleshooting

### My flashlight does not turn on or I cannot select a brightness level.

- Make sure that you installed the batteries correctly.
- Make sure that your flashlight is turned on.
- Replace the batteries.

### The flashlight body is overheating.

If you set the brightness level to high, the LED generates a moderate amount of heat. This is normal. If your flashlight is too hot to hold, turn it off and wait 10 minutes for it to cool.

## Specifications

**Dimensions (H x W):** 5.5 x 1.3 in.  
(13.8 x 3.2 cm)

**Weight (with batteries):** 5.3 oz. (151 g)

**Battery:** AAA size (3)

**IP rating:** IPX4 (rain and splash resistant)

**Impact resistance:** 3 ft. (1 m)

Beam selection modes	Output	Max. beam distance	Runtime (on fresh batteries)
Low	35LM	170 ft. (52 m)	25 hrs.
Medium	100LM	328 ft. (100 m)	8 hrs.
High	350LM	541 ft. (165 m)	4 hrs.

## Safety information

### Battery cautions:

- Do not mix batteries of different types or mix old and new batteries because the batteries might leak.
- Remove batteries when the charge is depleted.
- If your flashlight is not going to be used for an extended period of time, remove the batteries.
- Battery chemicals can cause a rash. If the batteries leak, clean the battery compartment with a cloth. If chemicals touch your skin, wash immediately.
- Make sure that batteries are disposed of correctly. Do not burn or incinerate.

### Flashlight cautions:

- Do not shine the flashlight into a person's eyes. This might damage the person's eyesight.
- When your flashlight is on, do not touch the flashlight head. The head may be hot enough to burn your skin.
- Keep your flashlight away from children under 18 years of age.

## One-year limited warranty

Visit [www.bestbuy.com/bestbuyessentials](http://www.bestbuy.com/bestbuyessentials) for details.

## Contact Best Buy essentials

For customer service, call 866-597-8427 (U.S. and Canada)

[www.bestbuy.com/bestbuyessentials](http://www.bestbuy.com/bestbuyessentials)

Best Buy essentials is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC  
7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2021 Best Buy. All rights reserved.