


## QUICK SETUP GUIDE

## Charging Station

NS-GNSJCCS18/NS-GNSJCCS18-C

## PACKAGE CONTENTS

- Charging Station
- AC adapter
- Quick Setup Guide




## FEATURES

- Charges up to four controllers simultaneously
- Easy slide-in design connects each controller to the charger
- Individual LEDs indicate the charge level for each controller
- Base rotates 360°
- Weighted base for stability
- External USB charging port for charging an additional device
- Compatible with Nintendo Switch Joy-Con™


## SETTING UP THE CHARGING STATION

- 1 Plug the AC adapter into a wall outlet, then plug the other end into the charging station.




- 2 Slide the controller down into a charging slot to charge. The LED indicator lights red when the controller is properly seated.

**Note:** Make sure that the controller slides into the charging station in an upright position.



STATUS LED	DESCRIPTION
Red	Charging in process
Green	Charging complete

- 3 When the LED indicator turns green, hold the release button on the back of the controller and slide it up to remove it from the charging station.




## USING THE EXTERNAL USB CHARGING PORT

To recharge your Switch Pro controller or other USB device, use the external USB charging port.

### Notes:

- Charging time for a controller or phone may vary based on the number of controllers charging at that time.
- The external USB charging port is designed to charge most USB 2.0 devices and might not charge newer devices.



## SPECIFICATIONS

<b>Dimensions (W×H×D)</b>	3.9 x 5.2 x 3.9 in. (9.9 x 13.2 x 9.9 cm)
<b>Input - Charge Station:</b> AC adapter:	DC 5V 3.0A AC 100-240V~50/60Hz 0.45A
<b>Output - AC adapter:</b> External USB charging port:	DC 5V 3.0A 5V 2.1A
<b>Charging time</b>	
1-4 controllers:	Approximately 2 hours 30 minutes to 3 hours
Switch Pro Controller:	Approximately 3~4 hours

## SAFETY INFORMATION

- You must use the included AC adapter to power the charging station.
- Do not disassemble any of the components. Refer all services to qualified personnel only.
- Do not place or store the product in a humid area and do not expose it to water or rain.
- Use the product only as instructed. Read all instructions before operating the product.
- Failure to follow these directions may void the warranty.

## LEGAL NOTICES

### FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if it is not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### ICES-003 Statement

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## ONE-YEAR LIMITED WARRANTY

Visit [www.insigniaproducts.com](http://www.insigniaproducts.com) for details.

## CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico) [www.insigniaproducts.com](http://www.insigniaproducts.com)

INSIGNIA is a trademark of Best Buy and its affiliated companies  
Distributed by Best Buy Purchasing, LLC  
7601 Penn Ave South, Richfield, MN 55423 U.S.A.  
©2017 Best Buy. All rights reserved.

**Made in China**