



RF-G1175 Mini/Micro HDMI Adapter


QUICK SETUP GUIDE

Thank you for purchasing this high quality Rocketfish HDMI adapter.


Package contents

- Mini/Micro HDMI adapter
- *Quick Setup Guide*

Features



Connect your HDMI compatible tablet or smartphone to your TV.



Using your HDMI adapter

Connect your HDMI compatible tablet, smartphone, or camera to your TV:

- 1 Plug the adapter's Micro HDMI-D connector or Mini HDMI-C connector (whichever fits) into your tablet, smartphone, or other source device.

Caution: Do not connect the adapter to two source devices like a tablet or smartphone at the same time. This adapter does not support simultaneous connections.

- 2 Plug one end of a standard HDMI cable (not included) into your display (TV, projector, monitor, etc.), then plug the other end into the HDMI adapter.
- 3 Turn on your display and select the HDMI input that you connected the HDMI cable to in step 2.
- 4 Turn on your source device (tablet, smartphone, camera, or similar device) and start output/playback.

Lifetime limited warranty

Visit www.rocketfishproducts.com for details.

Contact Rocketfish:


For customer service, call 1-800-620-2790
www.rocketfishproducts.com

© 2012 BBY Solutions, Inc. All Rights Reserved.

Distributed by Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, MN USA 55423-3645

ROCKETFISH is a trademark of BBY Solutions, Inc. All other products and brand names are trademarks of their respective owners.



***Connect only one device at a time.
Use either a Micro or Mini connection.**