

The Costway logo is centered, featuring a stylized house icon above the word "COSTWAY" in bold, uppercase letters. Below the logo is the tagline "WHERE THERE IS CUSTOMY THERE IS HOME". To the right of the logo is a QR code.

COSTWAY
www.costway.com

USER'S MANUAL

AIR COOLER

EP23666

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com

COSTWAY
 www.costway.com

INTRODUCTION

- Thank you for purchasing our air cooler.
- Each unit has been manufactured to ensure safety and reliability.
- Before first use, read the instructions carefully and keep it for further reference.

DIAGRAM

A detailed diagram of the Costway Air Cooler. The main unit is a rectangular box with a control panel on the left side. The control panel includes a 'Push key' at the bottom and a 'Water tank indicator' above it. A 'Water tank' is shown inside the unit, with a 'Water pump' and 'Water pipe' connected to it. An 'Air vent' is located on the top of the unit. A 'Remote control' is shown next to the unit. A 'Water filter screen' is shown at the top left, with an arrow indicating it is inserted into the top of the unit. The unit is labeled 'Caster' at the bottom.

PERFORMANCE PARAMETERS

Model	Rating Power	Fan power	Max Water Injection Rate	Specification
EP23666	110-120V~60Hz	75W	6.5L	14.5*12.6*28.9in

FUNCTIONS

- **Principle of cool humidity:** take cool water from the water tank by pump or synchronous motor, after reaching the top, the cooler will flow through the wet pad, then blow off humid cool air surrounding the wetted pad by rotational wind wheel. Use the water evaporation principle.
- **Electricities controls:** safe and durable, attractive appearance.
- **Adjustable speed and modes:** have three speeds and modes, blow a wide angle.
- **Cool humidity:** add ice crystal refrigeration and air humidifying technology, can cut down the temperature from air vent and raise relative humidity, prevent air drying.
- **Antibac purity and sterilize** air by generating negative ion.
- **Deliver wind at wide angle:** swing the blades automatically, deliver wind at horizontal wide angle. Also can swing the blades manually, select the direction discretely.
- **Far-range remote control:** 230m far-range remote control, receive at 60 degree wide-angle.
- **Buzzer:** vocalize when operating the effective keypad, use conveniently.

ASSEMBLING AND WATERING

1. Assemble casters: put the appliance on a flat surface, take out the wrench from foam box, then assemble the casters.

2

COSTWAY
www.costway.com

Attention: the back corners are with brake, but the front ones are without. (map 1)

2. **Warning:** push the key on the door, open it and draw out the water tank, then add water (map 2)
3. **Attention:**
 - a. Pay attention to the level of water tank when add water (map 3)
 - b. The "level" of water tank should not over "MAX" scale at any time, when humidifying, the total level of water tank should not below "MIN" scale.
 - c. Put ice or frozen ice crystal box to the water tank if you want to strengthen the efficiency of cooling, but the total level of water tank should not over "MAX" scale.

map 1

map 2

map 3

OPERATION

- **ON:** the appliance is plugged in and on the standby model, at the same time the buzzer reminds "BI". Press the key, start it.
- **OFF:** press the key, close it.
- **Speed:** press the key, start the air cooler. The corresponding function changes as follows when press serially:

press serially: Low → Mid → High
- **Mode:** press the key, choose the normal wind, natural wind and deeping wind circularly. Under the situation of normal wind it has no corresponding indicator light glowing, but others have.
- **Swing:** press the key, the wind swings horizontal automatically and the swing indicator light is on. Cancel this function when press again. Swing the blades unversally manually, select the direction desceendantly.
- **Asian:** press the key, the asian generator works and releases asian, at the same time the asian indicator light is on. Cancel this function when you press again.
- **Timer:** 75 hours timer design, each press adds 6.5 hours.
- **Cool/humidify:** press the key, if add frozen ice crystal box, the temperature from air vent can lower about 37°F after a few minutes. Cancel this function when press again.

THE USE OF REMOTE CONTROL

Fit on two batteries. Should aim at the reception window of remote control when you use, the effective distance must be 250m. When the remote control is not in use, please put away it for saving next time.

Attention:

- a. Do not use old battery with the new one in use.
- b. Please take out the batteries for long time onuse.

THE USE OF ICE CRYSTAL BOX

The ice crystal box has a particular feature of keeping cool, it can absorb heat and let the water

3

COSTWAY
www.costway.com

temperature below the environmental temperature.

Using methods:

- Add water to the ice crystal bins (not full) and add to the refrigerator to make sure it is cool absolutely.
- Open the door, put the frozen ice crystal bins into the water tank.
- There have no ice crystal bins, so can be used directly.

CAUTION

- Use as per the rating voltage.
- Do not repair or remake the appliance by yourself, it should be required by the repairman.
- Do not operate the appliance with wet hands, in order to avoid damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- When the appliance is not in use, switch off and unplug it.
- Do not insert foreign things in air outlets and inlets, in order to avoid damage.
- Do not use the appliance near explosive and combustible gas. Avoid long-term direct solar radiation.
- Use the appliance only on a flat surface.
- Do not use outdoors.
- The level of water tank should not over "MAX" scale at any time, when humidifying, the total level of water tank should be less than "MIN" scale.
- After adding water to the water tank, do not tilt or knock over it when you put or move. If you want to move, please push slowly from the side, in order to avoid spilling.
- Do not turn over the appliance. If it is tipped over and there is some water in the body, should unplug the power supply first. Then send it to repair department or after-sales service and overhaul the appliance.
- Do not cover the air vent.
- Clean the appearance with a lightly damp cloth. Do not use any type of detergents or solvents. Do not rinse the appliance.
- Do not make air outlets and inlets near the wall or curtain.
- Do not knock or shake the body when using, otherwise it may cause stop automatically.
- The water in tank will easily metamorphose and has odor in summer, please remove the water frequently.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- To avoid the risk caused by inability of unit, you must plug the unit firmly according to manual book.
- For the temperate climates only.
- Should it necessary to move the unit after the water has been added, roll gently to the required position and activate the bracket the controls.

ELECTRIC PRINCIPLE DIAGRAM

COSTWAY
www.costway.com

The diagram shows the electrical connections for the air purifier. A power plug (Brown and Blue) is connected to a central circuit board. The circuit board has four output terminals: 'ma' for the main motor, 'fa' for the fan motor, 'h' for the humidification motor, and 'a' for the anion generator. A transformer is connected to the circuit board via two lines.

CLEANING AND MAINTENANCE

The image contains four small photographs labeled 'map 1' through 'map 4'. Map 1 shows a hand pulling the power plug. Map 2 shows a hand cleaning a mesh screen. Map 3 shows a hand cleaning a rectangular water tank. Map 4 shows a hand cleaning a white plastic lid.

WARNING: Ensure that the fan is switched off from the supply mains before removing the air filter screen.

1. Clean the air filter screen (map 1)
Cut off the power supply, pull the handle of air filter screen, remove it from appliance.
Clean the air filter screen with neutral detergent and business brush, then clean it with clear water. Finally, reinstall to the appliance.
2. Clean the wetted pad (map2, map3)
Cut off the power supply, take down the air filter screen, then draw the wetted pad from support. Clean the wetted pad with neutral detergent and business brush, then clean it with clear water. Finally, reinstall to the appliance.
Attention: the wetted pad must be installed horizontally, in order to avoid leaking.
3. Clean the water tank (map-4)
Cut off the power supply, open the door, take out the water tank, clean it with neutral detergent, and wash it with clear water, then reinstall to the appliance.
4. Clean the shell
Clean with neutral detergent and soft cloth.
Attention: cut off the power supply when clean the shell, there have a high pressure in the body, do not leave any water on the surface of control panel.

5

COSTWAY
 www.costway.com

MAJFUNCTION AND MAINTENANCE

Malfunction	Causes	Solution
No action	1. Power off or poor connection. 2. Not press the "ON/OFF" key on the control panel.	1. Plug the power cord and make sure it connects well. 2. Press the "ON/OFF" key on the control panel.
Poor effect of dedusting	1. Block the air filter screens with dust. 2. Block the air inlet with corpus alienum	1. Purify the air filter screens. 2. Remove corpus alienum from the air inlet.

Repair the appliance under the situation as follows:

1. Abnormal action or no action, it is installed by the above approach.
2. Abnormal action caused by ingress of water or corpus alienum.

6

COSTWAY
www.costway.com

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us!
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far
February 24, 2019
Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS! and EFFICIENT SERVICE!

US office: Fontana, California
UK office: Ipswich



- Reward Points
- Exclusive Customer Service
- Personalized Recommendations
- Permanent Shopping Cart
- Order History

5 Star Rating

★★★★★★

We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.

THANK
You
😊

7