

USA office: Fontana AUS office: Truganina GBR office: Ipswich FRA office: Saint Vigor d'Yonneville

If you're having difficulty, our friendly customer team is always here to help.

USA.cs@costway.com AUS.cs@costway.com GBR.cs@costway.com FRA.cs@costway.com

Air Cooler  
Refridroisseur d'Air  
ES10348US-WH

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

## Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

## Avant de Commencer


- ⚠ Veuillez lire attentivement toutes les instructions.
- ⚠ Conservez les instructions pour vous y référer ultérieurement.
- ⚠ Vérifiez toutes les pièces et les accessoires.
- ⚠ Lisez attentivement chaque étape et suivez l'ordre correct.
- ⚠ Nous recommandons que, dans la mesure du possible, tous les produits soient assemblés à proximité de la zone où ils seront utilisés, afin d'éviter tout déplacement inutile du produit une fois assemblé.
- ⚠ Placez toujours le produit sur une surface plane et stable.
- ⚠ Conservez toutes les petites pièces de ce produit et les matériaux d'emballage hors de portée des bébés et des enfants, car ils pourraient présenter un risque d'étouffement.

02

EN  
INTRODUCTION

- Thank you for purchasing our air cooler.
- Each unit has been manufactured to ensure safety and reliability.
- Before first use, read the instructions carefully and keep them for further reference.

## DIAGRAM



## PERFORMANCE PARAMETERS

Model	Rating Power	Fan Power	Max Water Injection Rate	Specification
ES10348US-WH	110-120V~60Hz	75W	8L	16.14*12.99*28.54in

## FUNCTIONS


- **Principle of cool humidification:** take cool water from the water tank by pump or synchronous motor, after reaching the top, the cool water will flow through the wetted pad, then blow off humid air rounding the wetted pad by rotational wind wheel. Use the water evaporation principle.
- **Electronics control:** safe and durable, attractive appearance.
- **Adjustable speed and mode:** have three speeds and modes, blow at wide angle.
- **Cool/humidity:** adopt ice crystal refrigeration and air humidifying technology, can cut down the temperature from air vent and raise relative humidity, prevent air drying.
- **Anion:** purify and sterilize air by generating negative ion.
- **Deliver wind at wide angle:** swing the blades automatically, deliver wind at horizontal wide angle. Also can swing the blades transversely manually, and select the direction discretionarily.
- **Far-range remote control:** 236in far-range remote control, receive at 60 degree wide angle.
- **Buzzer:** vocalize when operating the effective keypad, use conveniently.

03

04

EN  
Return / Damage Claim Instructions

- ⚠ DO NOT discard the box / original packaging. In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
- ⚠ Take a photo of the box damage. A photo of the box damage on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
- ⚠ Take a photo of the damaged part (if applicable). Upon receiving the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
- ⚠ Send us an email with the images needed. Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.



## Instructions De Retour / Réclamation De Dommages

- ⚠ NE PAS jeter la boîte/ l'emballage d'origine. Dans le cas où un retour est requis, l'article doit être retourné dans sa boîte d'origine. Sans cela, votre retour ne sera pas accepté.
- ⚠ Prenez une photo des marquages de la boîte. Une photo des marquages (texte) sur le côté de la boîte est requise au cas où une pièce serait nécessaire pour le remplacement. Cela aide notre personnel à identifier votre numéro de produit pour s'assurer que vous recevez les bonnes pièces.
- ⚠ Prenez une photo des dommages (le cas échéant). Une photo des dommages est toujours requise pour déposer une réclamation et obtenir rapidement votre remplacement ou votre remboursement. Assurez-vous d'avoir la boîte même si elle est endommagée.
- ⚠ Envoyez-nous un e-mail avec les images demandées. Envoyez-nous un e-mail directement depuis le marché où votre article a été acheté avec les images ci-jointes et une description de votre réclamation.

21

EN  
ASSEMBLING AND WATERING

- 1. Assemble castors: put the appliance on a flat surface, take out the wrench from foam box, then assemble the castors.


Attention: the back castors are with brake, but the front ones are without. (map 1)

- 2. Watering: draw out the water tank, then add water. (map 2)

Attention: a. Pay attention to the level of water tank when adding water. (map 3)

b. The level of water tank should not over "MAX" scale at any time, when humidifying, the total level of water tank should not below "MIN" scale.

c. Put ice or frozen ice crystal box to the water tank if you want to strengthen the efficiency of cooling. But the total level of water tank should not over "MAX" scale.



## • OFF: press the key, close it.

- Speed: press the key, start the air cooler. The corresponding function changes as follows when pressed serially:

Low → Mid → High

- Mode: press the key, choose the normal wind, natural wind and sleeping wind circularly. Under the situation of normal wind it has no corresponding indicator light shining, but others have.

- Swing: press the key, the wind swings horizontally and automatically and the swing indicator light is on. Cancel this function when pressed again. Swing the blades transversely manually, select the direction discretionarily.

- Anion: press the key, the anion generator works and releases anion, at the same time the anion indicator light is on. Cancel this function when you press again.

- Timer: 7.5 hour timer design, each press adds 0.5 hour.

- Cool/humidity: press the key, if add frozen ice crystal box, the temperature from air vent can lower about 37 °F after a few minutes. Cancel this function when pressed again.

## COSTWAY COSTWAY

- **ON:** the appliance is plugged in and on the standby model, at the same time the buzzer reminders "Bi". Press the key, start it.

## Attention:

- a. Do not mix old battery with the new one in use.

- b. Please take out the batteries for long time nonuse.

## COSTWAY COSTWAY

## THE USE OF REMOTE CONTROL


Fit on two batteries. Should aim at the reception window of remote control when you use, the effective distance must be 236in. When the remote control is not in use, please put away it for next time.

## Attention:

- a. Do not mix old battery with the new one in use.

- b. Please take out the batteries for long time nonuse.

## NETTOYAGE ET ENTRETIEN



AVERTISSEMENT: Assurez-vous que le ventilateur est éteint du réseau d'alimentation avant de retirer le tamis du filtre à air.

- 1. Nettoyer le tamis du filtre à air (figure 1) Coupez l'alimentation électrique, tirez sur la poignée du filtre à air, retirez-le de l'appareil. Nettoyez le tamis du filtre à air avec un détergent neutre et une brosse de rampe, puis nettoyez-le à l'eau claire. Enfin, réinstallez-le sur l'appareil.

- 2. Nettoyer le tampon humide (figure 2, figure 3) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon mouillé du support. Nettoyez le tampon mouillé avec un détergent neutre et une brosse à rampe, puis nettoyez-le à l'eau claire. Enfin, réinstallez-le sur l'appareil.

- 3. Nettoyer le tamis du filtre à air (figure 4) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon mouillé du support. Nettoyez le tampon mouillé avec un détergent neutre et une brosse à rampe, puis nettoyez-le à l'eau claire. Enfin, réinstallez-le sur l'appareil.

- 4. Nettoyer le tampon humide (figure 2) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon mouillé du support. Nettoyez le tampon mouillé avec un détergent neutre et une brosse à rampe, puis nettoyez-le à l'eau claire. Enfin, réinstallez-le sur l'appareil.

- 5. Nettoyer le tampon humide (figure 3) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon mouillé du support. Nettoyez le tampon mouillé avec un détergent neutre et une brosse à rampe, puis nettoyez-le à l'eau claire. Enfin, réinstallez-le sur l'appareil.

- 6. Nettoyer le tampon humide (figure 4) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon mouillé du support. Nettoyez le tampon mouillé avec un détergent neutre et une brosse à rampe, puis nettoyez-le à l'eau claire. Enfin, réinstallez-le sur l'appareil.

- 7. Nettoyer le tampon humide (figure 1) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide.

- 8. Nettoyer le tampon humide (figure 2) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide.

- 9. Nettoyer le tampon humide (figure 3) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide.

- 10. Nettoyer le tampon humide (figure 4) Coupez l'alimentation électrique, démontez le tamis du filtre à air, puis nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide. Nettoyez le tampon humide avec un chiffon humide.

19

EN  
THE USE OF ICE CRYSTAL BOX

The ice crystal box has a particular feature of keeping cool, it can absorb heat and let the water temperature below the environmental temperature.

## Using methods:

- a. Add water to the ice crystal box (not full) and put it into the refrigerator to make sure it is iced absolutely.

- b. Open the door, put the frozen ice crystal box into the water tank.

There have two ice crystal boxes, so can be used circularly.

## CAUTION

- 1. Use as per the rating voltage.

- 2. Do not repair or remake the appliance by yourself, it should be repaired by the repairman.

- 3. Do not operate the appliance with wet hands, in order to avoid damage.

- 4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- 5. When the appliance is not in use, switch off and unplug it.

- 6. Do not insert foreign things to air outlets and inlets, in order to avoid damage.

- 7. Do not use the appliance near explosive and combustible gas. Avoid long-term direct solar radiation.

- 8. Use the appliance only on a flat surface.

- 9. Do not use outdoors.

## COSTWAY COSTWAY

## 10. The level of water tank should not over "MAX" scale at any time, when humidifying, the total level of water tank should not below "MIN" scale.

- 11. After adding water to the water tank, do not tilt or knock over it when you put or move. If you want to move, please push slowly from the side, in order to avoid spilling.

- 12. Do not turn over the appliance. If it is toppled over and there is some water in the body, should unplug the power supply first. Then send it to repair department or after-sales service and overhaul the appliance.

- 13. Do not cover the air vent.

- 14. Clean the appearance with a lightly damp cloth. Do not use any type of detergents or solutions. Do not rinse the appliance.

- 15. Do not make air outlets and inlets near the wall or curtain.

- 16. Do not knock or shake the body when using, otherwise it may cause stop automatically.

- 17. The water in tank will easily metamorphose and has odor in summer, please renew the water frequently.

- 18. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- 19. Children should be supervised to ensure that they do not play with the appliance.

- 20. To avoid the risk caused by instability of unit, you must fix the unit firmly according to manual book.

- 21. Fan for temperate climates only.

## COSTWAY COSTWAY

- 3. Ne faites pas fonctionner l'appareil avec les mains mouillées, afin d'éviter tout dommage.

- 4. Si le cordon d'alimentation est endommagé, il doit être remplacé par le fabricant, son agent de service ou des personnes de qualification similaire afin