


Marshall

EMBERTON – PORTABLE LOUDSPEAKER

USER MANUAL





DEVICE LAYOUT

ENGLISH

① CONTROL KNOB

I. POWER ON/OFF

Push and hold for 2 seconds

II. PLAY/PAUSE

Push once

III. SKIP FORWARD/BACK

Push to the right or the left

IV. FAST FORWARD/REWIND

Push to the right or left and hold

V. TURN UP/DOWN THE VOLUME

Push upwards or downwards

② BLUETOOTH® PAIRING BUTTON AND INDICATOR

Push the Bluetooth® button until the indicator above starts blinking to initiate Bluetooth pairing mode.

③ BATTERY INDICATOR

The 10 segment battery indicator shows the battery charge.

④ USB PORT FOR CHARGING

Connect the speaker to a power source via the included USB cable to charge the battery.

The battery is fully charged when the battery indicator stops blinking.

GETTING STARTED

01. Push the control knob for 2 seconds. The speaker turns on and is in pairing mode.
02. Select **EMBERTON** from your audio device's Bluetooth list.