INSIGNIA

QUICK SETUP GUIDE

32" LED TV NS-32D312NA15

Thank you

for purchasing this state-of-the-art
Insignia television. We hope you enjoy
the quality and reliability of this
television for years to come.



Roku Ready®

Your TV is certified to work with the Roku Streaming Stick™.

Instantly stream 1000+ entertainment channels, including Netflix, Hulu Plus, Pandora, and more. Connect the Streaming Stick (not included) to the purple MHL jack on your TV and enjoy.

FIND YOUR USER GUIDE ONLINE!

We are going green so a copy of your *User Guide* is not provided in the box but is available online.

Go to www.insigniaproducts.com, then click Support & Service. Enter your model number in the box under Manual, Fire & Service. Enter your model number in the box under Manual, Fire & Service. Enter your model number in the box under Manual, Fire & Service. Enter your model number in the box under Manual, Fire & Service. Enter your model number in the box under Manual, Fire & Service. Enter your the box under Manual, Titles Wester & Wester &




1 START HERE

How do I attach the stand to my TV? (not for wall mounting)

You'll need: Phillips screwdriver and a soft surface to lay the TV on.

- **A** Carefully place your TV face-down on a cushioned, clean surface to protect the screen.
- **B** Secure the stand to the TV with the four provided screws.







How do I prepare my TV for wall mounting

(not for use with a TV stand)

- **A** Carefully place your TV face-down on a cushioned, clean surface to protect the screen.
- **B** Remove the three screws that secure the stand column to the TV.
- **C** Remove the stand column.
- **D** See the instructions that came with your wall mount for more information about how to correctly mount your TV.






STOP!

Do not plug your power adapter in until all other devices have been connected.

Included accessories

Power adapter





TV stand

Which cables do you have?


Your TV has several different jacks for connecting devices. For the best video quality, use the best available connection. Use the cables that came with your devices.

VIDEO QUALITY	JACK TYPE	CABLE CONNECTOR
BEST	HDMI video/audio	
BETTER	Component video and analog audio	
GOOD	© © © Composite video and analog audio (AV)	
GOOD	Coaxial video/audio	

Note: You can also connect a DVI device to your TV. See your online *User Guide* for connection instructions.

Features


Front view




Note: Images do not necessarily represent the exact design of your television.

MAKING CONNECTIONS How do I watch TV (cable or s player, game console, Roku S Using an HDMI cable (BEST)






Multi-purpose jacks: You can plug any device that uses HDMI into either HDMI jack. However, certain devices must be connected to the ARC/DVI, or MHL jacks. See the instructions that came with your ARC, DVI, Roku Streaming Stick™, or MHL-enabled device for more information. Note: The HDMI 2 (ARC/DVI) jack is a shared jack. This means you can only connect one DVI or ARC device at a time.



How do I connect my TV to an antenna or cable wall jack?





3 CONNECTING AUDIO DEVICES How do I connect my TV to external speakers? Using digital audio On your TV, set the Digital Audio Format option on the AUDIO menu to PCM. Note: Refer to the instructions that came with your speakers for more information. OR Using analog audio

D void

When can I turn on my TV?


The best time to turn on your TV is after you have attached the TV

stand or wall-mounted your TV and connected all devices.

When your television is in place:

4 TURNING ON MY TV

Plug one end of the power cord into the DC IN connector on the back of your TV and the other end into a power outlet.



Note: Refer to the instructions that came


with your speakers for more information.

- Remove the remote control cover and install the batteries, matching the + and symbols.
- 3 Press () (power) on your remote
- **4** Follow the on-screen instructions.



Using your remote control

Roku Ready® means you can use your Insignia remote to control the Streaming Stick without having to pick up a different remote control.



I already have a universal remote control. How do I make it control this TV?

If you already have a universal remote control that you would like to program to work with your TV and don't want to use the included Insignia remote control, see the table for common codes.

	UNIVERSAL REMOTE TV CODES	
CABLE BOX, SATELLITE BOX, OR OTHER SET-TOP BOX		
Cablevision	068, 069, 078, 096, 100, 164, 168, 229, 026	
Charter	2002, 1204, 1423, 1517, 0171, 1963, 0463, 1463, 0842, 1326, 167, 415, 424, 450, 456, 461, 507, 523, 567, 577, 586	
Comcast	10171, 11204, 11326, 11463, 11517, 11641, 11780, 11785, 11892, 11963, 12002	
Cox	1326, 1463	
Direct TV	10171, 11204, 11326, 11517, 11564, 11641, 11963, 12002	
Dish Network	720	
Time Warner	400, 450, 461, 456, 10463, 1463, 0463	
Tivo	0091	
Verizon	0198, 0490	
	UNIVERSAL REMOTE CONTROLS	
One for All	0054	
Philips	0198, 0490	
RCA	135	
Sony	068, 069, 078, 096	



For an up-to-date list of codes for other cable providers and universal remote brands, scan this **QR code** or visit www.insigniaproducts.com/remotecodes

INSIGNIA

One-year limited warranty

Visit <u>www.insigniaproducts.com</u> for details.

Need additional help?

See your online *User Guide!* This comprehensive guide includes everything from basic how-to steps to more advanced features. A copy of your *User Guide* is not provided in the box but is available online. Go to www.insigniaproducts.com, then click **Support & Service**. Enter your model number in the box under **Manual**, **Firmware**, **Drivers & Product Information**, then click .

Check out our **Support Community**http://community.insigniaproducts.com/
for helpful information from other Insignia TV owners.

We're here for you

www.insigniaproducts.com

For customer service, call:

877-467-4289 (U.S./Canada)

INSIGNIA is a trademark of Best Buy and its affiliated companies.
Registered in some countries.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2014 Best Buy. All rights reserved.
Made in China