


Get to know your Fire TV Blaster



LED Indicators


Solid blue: Communicating with equipment.

Blue/cyan blinking: Setup in progress.

Purple: Setup timed out.


Solid orange: No network connection.

Off: Device is functioning.



Positioning your Fire TV Blaster


Place your Fire TV Blaster 1 to 2 feet away from devices you would like to control with the LED facing where you usually sit.




Fire TV Blaster requires a compatible Fire TV device and Echo smart speaker and adds voice control to compatible entertainment devices, such as your TV, soundbar, and receiver. Learn more at www.amazon.com/FireTVBlaster-Compatibility. It should be positioned within line of sight to your equipment and should not be obstructed or placed in a closed cabinet.

Controlling in-cabinet devices

To control entertainment components that are inside a closed cabinet, use the optional IR extender cable by plugging it into the back of your Fire TV Blaster as shown.




Place the IR extender cable on the same shelf as the devices you want to control (1). For devices on multiple shelves, place the IR extender cable on the lowest shelf (2).



Set up your Fire TV Blaster

Before you start, make sure that you have your Echo and Fire TV device set up and connected to the same Wi-Fi network.

1. Plug your Fire TV Blaster into a wall outlet using the included power adapter and cable.
2. Download the latest version of the free Fire TV app from the app store.
3. Open the Fire TV app and follow on-screen instructions to add your Fire TV Blaster.



4. Once your device is discovered and connected to the network, follow on-screen instructions to set up your Fire TV Blaster and configure your TV, soundbar, and other compatible IR remote-controlled devices.

5. To enable additional hands-free voice control, open the Alexa app to pair your Echo and Fire TV device.

Control your TV and sound devices

Follow the on-screen instructions in the Fire TV app to set up new entertainment devices.

Alexa, volume up.

Alexa, turn on the TV.

Alexa, turn off my receiver.

Troubleshooting

If you cannot discover the Fire TV Blaster restart it by unplugging the power cord then plugging it back in. The LED indicator will blink blue once it has restarted. Once it blinks blue and cyan, the Fire TV Blaster is ready to connect. Open the Fire TV app and follow the on-screen instructions to add your device.

If the Fire TV Blaster is not connected to your Wi-Fi network the LED indicator will be solid orange. Check your internet connection or change your Wi-Fi network.