



**Please give us a chance to make it right and do better !**

Contact our friendly customer service department for help first.  
Replacements for missing or damaged parts will be shipped ASAP !

**US** office: Fontana    **UK** office: Ipswich    **AU** office: Truganina  
**DE** office: Hamburg    **FR** office: Saint Vigor d'Ymonville    **PL** office: Gdańsk



## Contact Us!

**Do NOT return this item.**

Contact our friendly customer service department for help first.



US:cs.us@costway.com  
UK:cs.uk@costway.com  
AU:cs.au@costway.com

## USER'S MANUAL

### Christmas Tree CM23976

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



## Before You Start


- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Your item has been carefully packaged for transit. However, due to the nature of the materials used; some debris may appear in the bottom of the packaging or while unpacking. We have designed this item so its beauty will not be diminished by the debris. Due to the natural transit of this item, we have found that the item may flatten during packaging and need to be fluffed. Please know that this can be remedied by manually shaping to your desired look.

**NOTE** | For comfort and safety, we recommend wearing long sleeves and gloves to protect your arms and hands from branches during assembly.

## INSTALLATION INSTRUCTIONS:

1



Included Parts: Section A +  
Section B + Section C +  
Tree Stand + 3 Bolts

2



Unfold the tree stand.

3



Drop the section A into the tree stand.

4



Tighten the bolts into the tree stand.

7



Let the hinged branches fall into place.

8



Insert the section C into the section B.

5



Let the hinged branches fall into place.

6



Insert the section B into the section A.

9



Adjust the branch tips and put some decorations if desired. The angle of top is adjustable.



Fig.1



Fig.2



Fig.3

Notice: Spread out the branches as shown in the figure 1-3.

Please make sure to keep the instructions for reference when setting up your tree next year!

Made In China

Indoor Use Only

## **CARE INSTRUCTIONS:**

- If product becomes dusty or dirty, do not use detergent as it may discolor the product.
- When not in use, store in a cool, dry location.
- Keep away from heat and moisture.

## **TREE STORAGE:**


**Step 1:** Lift each tree section directly up.

**Step 2:** Separate the tree sections (starting at the top). Fold branches up to avoid crushing the tips. You can tie the branches up to make the section easier to handle and set up in future years.

**Step 3:** Unscrew tree stand to release the bottom section. Fold the stand and tighten bolts back into stand to prevent losing the bolts.

**Step 4:** Store in a cool, dry area.

## **Lighting Assembly**



Upper Interface




Lower Interface



Connect them together as shown in the picture



Controller+ Plug



Controller: The Christmas tree has 8 lighting modes, which can be adjusted by the controller.