



## PRO X Wireless LIGHTSPEED Gaming Headset

### INDEX

#### GETTING STARTED

- [Contents](#)
- [Features](#)
- [Headset setup](#)
- [Headset operation](#)

#### SPECIFICATIONS

- [Product Information](#)
- [Compliance](#)
- [Product Dimensions](#)
- [General Product Specifications](#)
- [Headset Specifications](#)

#### FAQs

- [Pair your PRO X 2 or PRO X headset to a new LIGHTSPEED wireless adapter](#)
- [How to customize surround sound with Logitech G HUB](#)
- [Logitech G HUB - FAQs](#)
  - [About Logitech G Hub](#)

#### WARRANTY

- [Hardware warranty](#)

## CONTACT US





- [Logitech Support](#)

## DOWNLOAD

- [G Hub](#)


# GETTING STARTED

## CONTENTS




## FEATURES

1. Microphone mute toggle
2. Volume wheel
3. Power switch
4. USB C charging port
5. Microphone



## HEADSET SETUP

1. Connect microphone to headset
2. Plug receiver into USB port
3. Turn on power switch
4. Download and install optional software



## HEADSET OPERATION

### Microphone mute toggle

- Microphone is active when red is not visible. Microphone is muted when red is visible.

### Volume wheel

- Rotate up to increase OS volume. Rotate down to decrease OS volume.

### Power switch

- Power is on when cyan is visible. Power is off when red is visible. Headset will power down automatically after 30 minutes of no audio to save battery life. To resume use, turn the power off, then back on again. Timeout value can be adjusted in G HUB.

### USB C charging port

- Use provided USB A to USB C charging cable to charge headset by plugging into USB port on PC. Cable is for charging and firmware update only – audio will not play over wired connection.

### Microphone

- For optimal voice pickup, place foam ball approximately two fingers' width from the corner of your mouth. Blue VO!CE functionality can be enabled using G HUB software.

## SPECIFICATIONS

Product Information		
Component	Model Number (M/N)	M/N Location
Headset	A00130	Under left ear pad
Receiver	A-00080	Bottom of the USB receiver

Compliance	
Document	Link
Certificates	Please contact Customer Service
Battery MSDS	Please contact Customer Service

Product Dimensions					
Component	Height	Length	Width	Weight (without cable)	Charging Cable Length
Headset	7.67 in (195 mm) w/o mic boom	5.43 in (138 mm) w/o mic boom	3.70 in (94 mm) w/o boom	370g with mic boom	1.8m (6.56 ft)
Receiver	0.33 in (8.4 mm)	0.75 in (19 mm)	2.28 in (58 mm)	0.28 oz (9 g)	N/A

General Product Specifications	
	At Release
Software Available	Logitech G HUB
OS/Platform Support	Windows® 7 or later
System Requirements	USB 2.0 Port and internet connection for optional software download

Headset Specifications	
Connection Type	USB
USB VID & PID	VID_046D & PID_0ABA
USB Protocol	2.0
USB Speed	High Speed
Headphone Type	Circumaural
Driver Type	Hybrid mesh PRO-G
Driver Size	50 mm
Headphone Sensitivity	91.7dB @ 1 mW & 1 cm
Headphone Frequency Response	20 Hz-20 kHz
Input Impedance	32 ohm
Magnet	Neodymium
Microphone Size	6mm
Microphone Pickup pattern	Unidirectional / Cardioid
Microphone Type	Electret Condenser



Headset Specifications	
Microphone Frequency Response	100Hz to 10 kHz
Earcup Audio Controls	Microphone mute Rotary volume control Power switch
Wireless Connection Type	2.4 GHz LIGHTSPEED
Wireless Range	Up to 15 m
Other Features	BLUE VO!CE microphone technology DTS Headphone:X 2.0 Removable earpads 1 x leatherette earpads 1 x velour earpads
Battery Life (Rechargeable)	Up to 20 hours* *Battery life may vary based on user and computing conditions. Up to 20h battery life is based on headset volume set to 50%.

## FAQs

- [Pair your PRO X 2 or PRO X headset to a new LIGHTSPEED wireless adapter](#)

If your device becomes unpaired or you receive a replacement LIGHTSPEED wireless adapter, do the following to pair your device:

1. Plug in the LIGHTSPEED wireless adapter.
2. Insert a pin into the reset port on the LIGHTSPEED wireless adapter to initiate pairing mode. The light on the adapter will blink.
3. Turn on the headset.
4. Remove the left ear pad on the headset.
5. Insert pin into pin-hole located below the speaker driver and between the lower two screws. The headset will blink and chime.




6. Wait 10-15 seconds for pairing to complete — blinking stops on both the headset and adapter and you'll hear a chime in the headset to indicate pairing is complete.

- [How to customize surround sound with Logitech G HUB](#)

You can use Logitech G HUB to customize surround sound settings on your Logitech G audio device.

**NOTE:** Make sure you're using the latest version of G HUB before you connect your Logitech G audio device to the computer. You can download the latest version of G HUB from the Download tab of your product's support page.

**G HUB Surround Sound Mixer On/Off** — click the check box for the Enable Surround Sound option in the G HUB Acoustics window to enable or disable surround sound on the gaming headset.



**Name** — you can choose from the following three multi-channel surround modes:

- Entertainment
- Gaming
- Sports

**DTS Super Stereo Mode** — you can choose from the following three Super Stereo Modes:

- Off
- Front
- Wide
- Traditional

**Audio Channel Volume Settings** — click the up or down arrows to adjust the volume level for each audio channel in the 7.1 surround sound configuration. The incremental adjustments range from 0 to 11.

**NOTE:** DTS Headphone:X 2.0 is available only on Windows

- [Logitech G HUB – FAQs](#)

**VIDEO:** [youtu.be/a5a4iAhTaho](https://youtu.be/a5a4iAhTaho)

## About G HUB

See the following link for more information:

<https://support.logi.com/hc/en-us/articles/4461144061975-Logitech-G-HUB-FAQs>

## WARRANTY – PRO X Wireless LIGHTSPEED Gaming Headset

[2 year limited hardware warranty](#)

See Terms of Use here: [logitech.com/en-my/tos/terms.html?id=3101](https://logitech.com/en-my/tos/terms.html?id=3101)

At Logitech, it is our goal to ensure you are completely satisfied with your Logitech purchase. We take pride in the products and services we offer, and want our customers to enjoy them just as much as we do. If you are experiencing an issue, please click on the following link to learn more about the Logitech warranty.

Check our Logitech Warranty here:

<https://support.logi.com/hc/en-us/articles/360023361413-Warranty-FAQ-AMR-AP>

## CONTACT US

Would you like to speak with us? We're here to help.

Get 24/7 live support with chat here: [logitech.com/support](https://logitech.com/support)

Phone: (Local) +1 646-454-3200

(Toll Free) +1 866-632-5644

Monday – Friday:

**9:00 a.m. – 9:00 p.m. Eastern Time**

## DOWNLOAD

See here to download G Hub:

[download01.logi.com/web/ftp/pub/techsupport/gaming/lghub\\_installer.zip](https://download01.logi.com/web/ftp/pub/techsupport/gaming/lghub_installer.zip)