

**DX-DGPK03**

## Ultimate Accessory Kit for GoPro

### FEATURES

- Compatible with most GoPro cameras
- Perfect for capturing hiking, biking, rock climbing, skiing, snowboarding, boating, swimming, and other activities


### PACKAGE CONTENTS

- Assorted accessories (see table)
- Note:** Place your GoPro inside its housing (included with or attached to your GoPro, not included with this kit) to mount with these accessories.
- *Quick Setup Guide*

Before using your new product, please read these instructions to prevent any damage.

### QUICK SETUP GUIDE

ITEM	DESCRIPTION
	<p>Use in any situation where you risk losing your GoPro if it falls (for example, while boating or biking). Connect directly to your GoPro and a fixed object such as a boat railing, sideview mirror, or other suitable location.</p> <p><b>Note:</b> Do not attach safety cable to your body, clothing, or safety gear.</p>
	<p>Attach your Go Pro using the thumb screw. Adjust the head strap mount to fit comfortably and securely.</p>
	<p>Push the surface J-hook into the grooves on the chest mount until it clicks into place, then attach your GoPro using the thumb screw. Adjust the chest straps to fit comfortably and securely.</p> <p><b>Note:</b> To remove, press the buckle on the J-hook, then slide it out.</p>
	<p>Attach your GoPro using the thumb screw. Adjust the strap to securely fit your arm, leg, or other object.</p>
	<p>To attach to bike handlebars, ski poles, and other objects, loosen the handlebar mount's thumb screws, align the mount where you want to attach it, then tighten the screws. Use one of the two adapters to rotate your GoPro 90 degrees.</p>

ITEM	DESCRIPTION
	<p>Clean and dry the mounting surface. Remove one side of the adhesive backing and press firmly onto the back of the mount, remove the other side of the adhesive back, press firmly on the mounting surface, then wait 24 hours. Attach your GoPro to the surface J-hook, surface quick release buckle, or 3-way adjustable pivot arm, then slide it into the adhesive mount.</p>
	<p>To attach to cars, boats, or other vehicles, screw the tripod mount adapter into the mount holder, then attach your GoPro using the thumb screw. Press the suction cup to your vehicle's surface, then push down the lock.</p> <p><b>Note:</b> Attach the safety cable to prevent your GoPro from falling off.</p>
	<p>To attach to cars, boats, or other vehicles, attach your GoPro to the surface quick release buckle, or surface J-hook, or 3-way adjustable pivot arm, then attach it to the mount. Press the suction cup to your vehicle's surface, then push down the lock.</p> <p><b>Note:</b> Attach the safety cable to prevent your GoPro from falling off.</p>
	<p>Attach your GoPro to the tripod mount adapter, then screw it onto the tripod. Stand the tripod upright or wrap the foam legs around objects for better placement.</p>

ITEM	DESCRIPTION
	<p>Use as a short handle for filming or to keep your GoPro afloat in water. Put your GoPro into a waterproof housing (not included), then attach it to the floating handle grip using the thumb screw.</p>
	<p>Attach your GoPro to the monopod with the thumb screw to capture striking perspectives, individual shots, or group shots. Twist to loosen the monopod, pull to extend it to the desired length you want, then twist again to secure.</p> <p><b>Note:</b> DO NOT force the monopod open or closed. It will slide freely when properly loosened.</p>
	<p>Use with the flexible tripod, car suction cup mount, or any other standard tripod that you own.</p>
	<p>Use to quickly attach and remove your GoPro while using the flexible tripod or other support systems. Attach your GoPro to the surface quick release buckle, surface J-hook, or 3-way adjustable pivot arm, then attach it to the quick release tripod mount adapter.</p>
	<p>Use with the chest mount, adhesive mount set, adjustable car suction cup mount, or quick release tripod mount.</p>

ITEM	DESCRIPTION
Surface quick release buckle 	Use with the chest mount, adhesive mount set, adjustable car suction cup mount, or quick release tripod mount.
3-way adjustable pivot arm 	Use with the chest mount, adhesive mount set, adjustable car suction cup mount, or quick release tripod mount.
360-degree rotary clip mount 	To quickly attach or remove your GoPro from a belt, bag, or other location, attach your GoPro using the thumb screw then clip it in place.
Thumb screws 	Use to secure your GoPro to mounts or adapters in this kit or as replacements for other accessories.

ITEM	DESCRIPTION
Anti-fog inserts 	To reduce lens fog in cold or humid environments, place an insert between your GoPro and its waterproof housing. To reuse the inserts, place on a clean metal pan and put inside a 300°F oven for five minutes. Inserts work for approximately three uses before losing effectiveness.
Micro USB cable 	Connect the small end (Micro USB) to your GoPro (if supported) and the large end (Type A) to your computer to charge your GoPro and transfer videos and pictures.
USB Type C cable 	Connect the small end (Type C) to your GoPro (if supported) and the large end (Type A) to your computer to charge your GoPro and transfer videos and pictures.
HDMI cable 	Connect to an HDTV, projector, or other screen.
Storage pouch 	Convenient transportation for your GoPro and a few accessories.

ITEM	DESCRIPTION
Carrying case 	Protect your GoPro and accessories in this padded case.

### THREE-MONTH LIMITED WARRANTY

Visit [www.dynexproducts.com](http://www.dynexproducts.com) for details.

### CONTACT DYNEX:

For customer service, call 800-305-2204 (U.S. and Canada) or 01-800-926-3020 (Mexico) or [www.dynexproducts.com](http://www.dynexproducts.com)

GOPRO, HERO, the GOPRO logo, and the GoPro Be a Hero logo are trademarks or registered trademarks of GoPro, Inc.

DYNEX is a trademark of Best Buy and its affiliated companies. Distributed by Best Buy Purchasing, LLC 7601 Penn Ave South, Richfield, MN 55423 U.S.A. ©2016 Best Buy. All rights reserved. **Made in China**