


Roku Ultra



Quick Start Guide

What's included



Roku Ultra streaming player



Remote




Headphones for private listening



Power adaptor



USB charging cable




Premium High Speed HDMI® Cable

Details



Let's get started

1




STEP 1: Connect to TV

Connect your streaming player to an HDMI port on the back of your TV with the included cable.

TIP:

For help setting up your device, visit go.roku.com/ultra


2



STEP 2: Connect to power

Use the included power adaptor to connect your streaming player to a wall outlet.


3



STEP 3: Select input


Use your TV remote to power on your TV and select the input (source) you used to connect your streaming player.

4



STEP 4: Pair your remote

Press and hold the pairing button on your remote for 5 seconds until the status light turns green and starts blinking. Your remote will pair automatically.



STEP 5: Follow the on-screen setup

Follow the instructions on your TV screen. Activate your streaming player by using your computer or smartphone to link a Roku account.

IMPORTANT:

Roku never charges for activation support.

Common questions

Why do I need to create a Roku account?

You'll need a Roku account to stream, add channels, easily manage subscriptions, rent movies, and more.

Why should I enter a credit card?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

Can I still give voice commands if I turn off hands-free voice?

Yes you can! Just press and hold the voice button to give a command instead. You don't need to say "Hey Roku" when using push-to-talk voice.

Visit go.roku.com/ultra for more information

Remote features



Private listening

Plug headphones into your remote to use private listening. Your TV will mute automatically.



Lost remote finder

Say "Hey Roku, where's my remote?" or press the button on your streaming player to locate it.



Personal shortcuts

Quickly launch a channel, play your favorite playlist, and more in a tap.

To set: Press a personal shortcut button for on-screen instructions.

Just talk to it. It's that easy.



Play entertainment

"Hey Roku, launch The Roku Channel"
"Hey Roku, play classic rock"



Control your streaming

"Hey Roku, pause"
"Hey Roku, turn captions on"



Control your TV

"Hey Roku, turn my TV off"
"Hey Roku, turn it up"




Find more to watch

"Hey Roku, show me the news"
"Hey Roku, search for comedies"

TIP:

For the best experience, keep the remote near you and speak towards it when giving a command.

Charging your remote



Connect your remote to the USB charging cable and either:

- the USB port on the back of your player
- a wall outlet using a standard USB adaptor (like your phone charger)

The status light will stop blinking once your remote is finished charging.

You'll see a message on your TV when it's time to charge again.

Need more help?

support.roku.com



Video
tutorials



Wi-Fi®
help

Cut cable. Save money. Stream big.

streamandsave.com



Free
TV



Live
TV

See what's streaming for free, tips, and more

Visit roku.com/blog

Follow us



Roku

© 2022 Roku, Inc. All rights reserved. Roku and the Roku logo are the registered trademarks of Roku, Inc. All other logos and trademarks herein not owned by Roku, Inc. are the property of their respective owners.

