

600 Film Set (Color/B&W)

In the mood for a little double trouble? We know one pack of film is never enough, so we made this 600 Film Set – one pack of Color 600 Film, and one pack of B&W 600 Film, packed lovingly into a single box. Plus they're each wrapped individually, so they'll stay fresh until you're ready to shoot. So you get a little variety, and for a lower price than if you'd bought each pack separately. It's the little things that help.



2 x 8 Instant Photos

Classic white frame

ASA 640^[1]

Photos develop in 5-10 mins (B&W)
10-15 mins (Color)

Best stored refrigerated^[2]

[1] Film speed may vary, allow for +/- 1/3 stops

[2] Do not freeze the film



Format

3.5" x 4.25" (8.8 cm x 10.8 cm)

Image Area

3.1" x 3.1" (7.9 cm x 7.9 cm)

Finish

Glossy

HS or HTS code

37012000

PRD #

004844

EAN #

9120066088819

Battery report (UN38.3)

Available

Warranty info

polaroidoriginals.com/warranty

Store chilled, shoot warm

Temperature affects how the film works. Keep it stored cold in the fridge, but never freeze it. Ideally you should let it adjust to room temperature before you use it. That's around 55-82°F (13-28°C). When it's cold out, keep your photos warm in a pocket close to your body while they develop. Or if it's a hot day, make sure they stay cool.

Shoot with the light

The more light in your shot, the better your photo will turn out. Instant film loves light, especially natural light. Use the flash for all your indoor photos. For best results we also recommend using the flash for outdoor shots, unless it's a bright sunny day.


Develop in the dark

All photos appear blank at first. They're most sensitive during this time, so don't bend or shake them. Shield them from the light, and place them face down as they develop. Keep B&W photos shielded from light for about 1 minute, and color film for about 6 minutes.


Care for your camera

Your camera has a set of rollers inside the film door. Each photo passes through these rollers as it's made, so it's important to make sure that they stay clean. If the rollers get visibly dirty then gently wipe them down with a soft, damp cloth.

For use with:



Polaroid
Impulse



Polaroid 600™



Polaroid SLR680



Polaroid i-Type



Impossible i-Type



Impossible
Instant Lab

Have a problem,
or a question you
need answered?

USA/Canada
usa@polaroidoriginals.com
1-212-219-3254

**Contact our
Customer
Support Team**

EU/Rest of World
service@polaroidoriginals.com
00800 5770 1500

or visit polaroidoriginals.com/help