




Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich



COSTWAY®

Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US:cs.us@costway.com
UK:cs.uk@costway.com

USER'S MANUAL




**TV Cabinet
HW64063**

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.




Before You Start

- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



★ Hardware inside



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care


It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.


Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.



27






28




NOTE : Wall fixings are not supplied with this product as different wall materials require different types of fixing devices (such as Rawl plugs on brick work). You must use fixing devices suitable for the type of wall you intend to mount this product to. Please ensure that the head of any screw used has a diameter greater than the diameter of the mounting hole on the bracket and that the fixing is safe and secure before use.
The screw supplied is to fix the anti-tip strap to the cabinet.




1		x10	2		x8	3		x29	4		x29
Ø15 x 23mm			M3.5 x 12mm			Dia 15mm 12mm			M6.5 x 32mm		
5		x30	6		x12	7		x2	8		x16
Dia 6 x 30mm			M8 x 38mm			PVC H 732mm			BACKPLY STOPPER		
9		x16	10		x2	11		x2	12		x24
M3 x 20mm			ANTI TIP STRAP			Glue 10cc			Dia 5 x 16mm		
13		x4	14		x1	15		x1	16		x1
DOOR HOLDER			M4			ALUMINIUM STRIP 1202mm			1203mm		
17		x5	18		x8	19		x4			
Dia 1/4 x 25mm			Dia 1/4 x 12mm			PULLEY					

25




- 9**  **x16**
M3 x 20mm
- 8**  **x16**
BACKPLY STOPPER

26




NOTE : THE MAXIMUM WEIGHT ON TOP PANEL UP TO 35KGS / 5KGS MAX WEIGHT PER SHELF .

23




- 18 x8
Dia 1/4 x 12mm
- 19 x4
PULLEY

1




- 4 x12
M6.5 x 32mm





24



2




- 4 x7
M6.5 x 32mm




19

TOP SIDE MARKING




- 7** x2
PVC H 792mm
- 16** x1
1203mm

5




- 5** x6
Dia 6 x 30mm
- 11** x1
Glue 10cc

6




- 5** x6
Dia 6 x 30mm
- 11** x1
Glue 10cc

20



- 3** x12
Dia 15mm


7



5 x4
Dia 6 x 30mm

11 x1
Glue 10cc


8



5 x4
Dia 6 x 30mm

11 x1
Glue 10cc

17




3 x7
LOCK

6 x4
M8 x 38mm

3 x7
Dia 15mm
12mm

6 x4
M8 x 38mm



18




1 x10

1 x10
Ø15 x 23mm



15






9




16





10






11






(x2)




13



14



12



11 x1

