

INSIGNIA™

Quick Setup Guide | NS-SFLX6B / NS-SFLX6B-C
6" Flexible Tripod

Congratulations on your purchase of a high-quality Insignia product. Your new tripod is designed for reliable and trouble-free performance.

PACKAGE CONTENTS

- 6" flexible tripod
- *Quick Setup Guide*

FEATURES

- 1.8 lb. (0.8 kg) load capacity for compact cameras or pocket video cameras
- Flexible legs can bend 360° to wrap around objects such as fences, tree branches, or chair legs
- Rubber non-slip feet for stability
- Protective foam shell around legs
- 1/4" mounting screw fits most cameras



Before using your new product, please read these instructions to prevent any damage.



| COMPONENT | DESCRIPTION |
|----------------|---|
| Mounting screw | Secures your camera or camcorder to the tripod. |
| Ball head | Rotates to tilt camera horizontally and vertically. |
| Lock screw | Locks ball head in place. |
| Leg | Bends 360° to wrap around objects. |
| Non-slip foot | Provides extra grip on various surfaces. |

USING YOUR TRIPOD

- 1 Unscrew (turn counter-clockwise) the lock screw to release the ball head.
- 2 Align the bottom of your camera with the tripod mounting screw, then secure your camera by rotating the ball head counter-clockwise. Make sure that the screw is tight.

- 3 Move the ball head to point the camera into position, then screw (turn clockwise) the lock screw against the ball head to lock it in place.
- 4 Wrap all three tripod legs completely around a secure object or place on the floor or a tabletop.
Caution: Not wrapping the legs completely around an object, or attaching to an unsteady object, could result in damage to the tripod or equipment mounted on the tripod.
- 5 To remove your camera from the tripod, unscrew the lock screw to release the ball head, then hold the camera in place and rotate the ball head clockwise.

IMPORTANT SAFETY INSTRUCTIONS

- Do not store or expose your tripod to excessive heat or cold, or use near any flame or fire.
- Do not oil or grease any part of the tripod.
- Do not use any solvents or thinners to clean your tripod. Use only a mild detergent and wipe dry with a soft, lint-free cloth.
- Do not exceed the load limit (1.8 lb or 0.8 kg) of this product.

SPECIFICATIONS

- Folded height: 6" (15 cm)
- Load capacity: 1.8 lb (0.8 kg)
- Weight: 1.8 oz. (52 g)
- Mounting screw: 1/4"

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Registered in some countries.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2015 Best Buy. All rights reserved.

Made in China