




User Manual

1.0 Introduction



Note:

*Before using the watch for the first time, ensure you charge it using the provided cable to activate and turn on the device.

*You can customize the screen-on time between 5 to 20 seconds by navigating to: Settings > Brightness > Screen-On Time.

1. Open the package and carefully inspect the contents.
2. Package Contents: TOZO S5 Smart Watch*1 (1 unit, with a built-in lithium battery), User Manual*1, Charging Cable*1.
3. To begin using your watch, connect the magnetic charging cable to the contact points on the watch to charge, activate, and turn on the device.
4. Search for "TOZO Wear" in the app store or scan the provided QR code (located on the right) to download and install the app.



5. Pairing: Open the TOZO Wear app, tap the "More" icon located in the upper right corner, select "Add Device", choose the device category that corresponds to your watch, and select your watch from the search list. Alternatively, you can quickly link your device by scanning the QR code on your watch using the app's scanning feature.

2.0 Device Connection

2.1 Adding Device by Search

1. Open the app, go to the "Device" page, and click "Add Device."
2. Search and select the device's MAC address.
3. Confirm pairing on the watch.
4. Confirm pairing request on the phone.
5. Successfully connected.

2.2 Adding Device by Scanning

1. Open the app, go to the "Device" page, and click the scan icon.
2. Scan the device's QR code.
3. Confirm pairing on the watch.
4. Confirm pairing request on the phone.
5. Successfully connected.

3.0 Charging Instructions

1. Place the charger close to the charging point on the back of the watch. The watch and charger will automatically attach.
2. The charging interface will appear on the watch.
3. The watch will indicate 100% charge when complete.



4.0 Button Functions

4.1 Function Button

1. Press and hold for 3 seconds to power on/off the device.
2. Short press from the main watch face to access the menu list; short press in the menu interface to return to the main watch face.
3. Short press in the app interface to return to the main watch face.
4. Short press to wake up the screen when it's off.
5. Short press during screen-on fitness mode to access pause/resume/lock screen/volume options.

4.2 Sport Button

1. Short press to access the "Exercise" mode list, including outdoor running, indoor running, outdoor walking, outdoor cycling, and more.
2. Short press again in the exercise list to enter the exercise screen and browse data.



5.0 Watch Face Switching

1. Long press the screen on the main watch face, and swipe left or right to select an image, tap the selected image to switch.
2. Settings → Watch Face and Cards → Watch Face → Swipe left or right to select an image, and tap the selected image to switch.

6.0 Menu Guide

1. Exercise: Choose from various exercise modes like outdoor running, indoor running, outdoor walking, outdoor cycling, etc. And set individual exercise goals: distance, time, calories, or no goal.




2. Exercise Records: Save exercise records; up to 40 records can be stored. If there are more than 40 records, they will start to be overwritten from the first record.
3. Heart Rate: Real-time heart rate monitoring for 24 hours, recorded every 5 minutes. You can view historical heart rate records through the app. The full heart rate monitoring feature is enabled by default and can be turned on/off in the app.
4. Blood Oxygen: Manually test blood oxygen saturation.
5. Activity Records: Record daily steps, moderate exercise time, and active hours.
6. Sleep: Monitor sleep quality, including sleep onset time, wake-up time, sleep stages (awake, light sleep, deep sleep), and sleep duration.
7. Music: Control phone music, switch songs, set playback modes, and adjust the phone's volume using the watch.
8. Weather: Display the weather for the current day and the next three days for your location.

- 9. Stopwatch: Timekeeping with lap function.
- 10. Timer: Set timers up to 23 hours, 59 minutes, 59 seconds.
- 11. Alarm: Set alarms on the watch or sync from the app.
- 12. Flashlight: Activate the flashlight.
- 13. Find Phone: Make the phone vibrate and ring.


7.0 Call Function

- 1. Compatible with voice call with features such as dial/answer/mute and reject calls as long as the smartphone is nearby and connected to the watch.
- 2. It takes in 10 contacts from your phone via "TOZO Wear" for speed dial.
- 3. You may dial a number or call up a contact from the call log on the watch.



8.0 Reminder Function


The watch supports multiple reminder modes including message reminders, incoming call reminders, low-power reminders, health reminders, alarm reminders, etc.



9.0 Settings

1. Watch Face & Card: Select dials, screen-off display, and card settings.
2. Display & Brightness: Adjust brightness, screen-off time, and always-on time.
3. Sound Settings: Adjust ringtone volume, enable/disable mute mode.
4. Do Not Disturb Mode: Choose full-day or time Do Not Disturb Mode.

5. Vibration Intensity: Adjust watch vibration strength.
6. System Menu: Power off/restart the watch, factory reset, or connect the new phone.
7. User Guide: Scan the QR code for tutorials.
8. About: Display watch name, model, and MAC address.



10.0 Pull-Down Menu

1. Do Not Disturb Mode: Enable all-day Do Not Disturb Mode. All reminder-related functions do not vibrate or ring except for alarms.
2. Mute: Enable mute mode except for alarms.
3. Wake on Wrist Raise: Enable the Wake on Wrist Raise feature.
4. Brightness Setting: 5 levels of brightness, default is level 3.
5. Settings: Access the settings menu.

11.0 Pull-Up Menu

Notifications: Requires enabling notifications in the app .

12.0 EU Battery Regulation



This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product shall not be treated as household waste. Instead, please separate battery(ies) from other types of waste and recycle it (them) through your local recycling system to protect environment and health. (When Cd is more than 20ppm or Pb is more than 40ppm, the chemical symbol of the excess substance shall be marked under the separate collection symbol) For more detailed information about recycling of this battery(ies), please contact your local authority or the shop where you purchased the product or battery(ies).

13.0 FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

14.0 ISED Compliance Statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

14.0 CE-DOC

Hereby, [Manufacturer] declares that the radio equipment type [Model No.] is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: www.tozostore.com

**Warning****EN**

Warning: Avoid dropping and do not disassemble. Do not charge when the products are wet. Avoid extreme high or low temperatures. Do not expose this product to excessive temperatures such as sunlight or fire. Use original or certified cables. Keep away from children. The included small parts may cause a choking hazard.

JP

警告: 落下や商品の分解を避けてください。製品が濡れているときには充電しないでください。また、極端な高温や低温、日光や火などの過度の温度にさらさないようにしてください。ぜひ認定済みのケーブルをご使用ください。お子様の手の届かない場所に保管し、付属の小さな部品は窒息の危険がありますのでご注意ください。

DE

Warnung: Nicht fallen lassen und nicht auseinandernehmen. Nicht aufladen, wenn die Produkte nass sind. Extrem hohe oder niedrige Temperaturen vermeiden. Dieses Produkt keinen übermäßigen Temperaturen wie Sonnenlicht oder Feuer aussetzen. Verwenden Sie Originalkabel oder zertifizierte Kabel. Von Kindern fernhalten. Die enthaltenen Kleinteile können eine Erstickungsgefahr darstellen.

FR

Attention: Évitez de le faire tomber et ne le démontez pas. Ne chargez pas les produits lorsqu'ils sont mouillés. Évitez les températures extrêmement élevées ou basses. N'exposez pas ce produit à des températures excessives telles que la lumière du soleil ou le feu. Utilisez des câbles d'origine ou certifiés. Tenir hors de portée des enfants. Les petites pièces fournies peuvent présenter un risque d'étouffement.

IT

Attenzione: evitare di far cadere e non smontare. Non caricare i prodotti quando sono bagnati. Evitare temperature estremamente alte o basse. Non esporre questo prodotto a temperature eccessive come luce solare o fuoco. Utilizzare cavi originali o certificati. Tenere lontano dalla portata dei bambini. Le piccole parti incluse possono causare un rischio di soffocamento.

ES

Advertencia: Evite que se caigan y no desarme. No cargue el producto cuando esté mojado. Evite temperaturas extremadamente altas o bajas. No exponga este producto a temperaturas excesivas, como la luz solar o el fuego. Utilice cables originales o certificados. Manténgalo alejado de los niños. Las piezas pequeñas incluidas pueden provocar peligro de asfixia.

NL

Waarschuwing: Laat het niet vallen en haal het niet uit elkaar. Laad het product niet op als het nat is. Vermijd extreem hoge of lage temperaturen. Stel dit product niet bloot aan extreme temperaturen zoals zonlicht of vuur. Gebruik originele of gecertificeerde kabels. Houd het buiten bereik van kinderen. De meegeleverde kleine onderdelen kunnen verstikkingsgevaar opleveren.

SE

Varning: Undvik att tappa och ta inte isär. Ladda inte när produkterna är blöta. Undvik extremt höga eller låga temperaturer. Utsätt inte denna produkt för höga temperaturer som solljus eller eld. Använd original eller certifierade kablar. Förvaras åtskilt från barn. De medföljande små delarna kan orsaka kvävningsrisk.

TR.

Uyarı: Düşürmeyin ve sökmeyin. Ürünler ıslakken şarj etmeyin. Aşırı yüksek veya düşük sıcaklıklardan kaçının. Bu ürünü güneş ışığı veya ateş gibi aşırı sıcaklıklara maruz bırakmayın. Orijinal veya sertifikalı kablolar kullanın. Çocuklardan uzak tutun. Dahil edilen küçük parçalar boğulma tehlikesine neden olabilir.

PL.

Ostrzeżenie: Unikaj upuszczania i nie rozmontowuj. Nie ładuj, gdy produkty są mokre. Unikaj ekstremalnie wysokich lub niskich temperatur. Nie wystawiaj tego produktu na działanie nadmiernych temperatur, takich jak światło słoneczne lub ogień. Używaj oryginalnych lub certyfikowanych kabli. Trzymaj z dala od dzieci. Dołączone małe części mogą powodować ryzyko zadławienia.



FR

ÉLÉMENTS D'EMBALLAGE
À SÉPARER ET À DÉPOSER
DANS LE BAC DE TRI



FR

Cet appareil,
ses accessoires,
cordons et batteries
se recyclent

À DÉPOSER
EN MAGASINÀ DÉPOSER
EN DÉCHÈTRE

OU

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !



The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5.0 Watts in order to achieve the maximum charging speed.



Scan the QR code to get the
manual in other languages



RoHS



Thank you for purchasing the TOZO authentic product.

For more latest products, parts and accessories,
please visit: **www.tozostore.com**

For any assistance please contact Email: **info@tozostore.com**