


PACKAGE CONTENTS

- In-Cabinet Remote Control Extender Kit
- AC adapter
- *Quick Setup Guide*

FEATURES


- Enables remote control of four Audio/Video (AV) devices that are located behind closed doors, cabinets, or walls
- Simple to install and use
- Long cable lengths allow for AV devices to be placed up to 10 ft. (3 meters) from the remote control (IR) receiver
- Built-in adhesive for easy attachment to AV devices




#	DESCRIPTION	FUNCTION
1	USB power connector	Connect to the AC adapter or a USB port on the TV or monitor.
2	Remote control receiver (IR)	Receives the signal from the remote control.
3	Emitters (IR)	Transmits remote control signals to the AV devices.
4	AC adapter	Connect to a wall outlet.

SETTING UP YOUR EXTENDER KIT

1 Locate your AV device's remote control (IR) sensor. To find it, shine a flashlight at the front of your AV device and look for an "eye" that resembles the emitters on the cable. If you can't locate it, check the documentation that came with your AV device.




2 Remove the adhesive backing from an emitter, then stick it **close to and pointed towards the remote sensor** on your AV device.



3 Remove the adhesive backing from the remote control receiver, then stick it to the front of your AV cabinet or on or near your TV. It needs to be in the line-of-sight of your remote control. Be sure it does not cover the remote control sensor on your TV.

4 Connect the USB power connector to either the TV's USB port or to the AC adapter and then into a wall outlet.

5 Aim the AV device's remote control at the remote control receiver.
Note: The emitters and receiver work with infrared, not visible, light, just like your remote control (so you won't see any lights blinking or flashing).



TROUBLESHOOTING

No power.

- Make sure that the USB connector is connected to either the TV's USB port or to the AC adapter and then into a working wall outlet.
- On some TV's, the USB port may not be powered when the TV is turned off. If that happens with your TV, either turn on your TV or use the included AC adapter.

My source device remote does not control the audio/video.

- Aim your AV device remote at the remote control receiver.
- Make sure that the emitters are close to and pointed at the remote sensors on your AV devices.
- Make sure that the remote control receiver does **not** cover the remote sensor on your TV.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

©2016 Best Buy. All rights reserved.

Made in China