



HGN782 HAGNEY LANE L-SHAPED DESK



Assembly Instructions - Important:

Carefully unpack and identify each component before attempting to assemble. Refer to parts list. Please take care when assembling the unit and always set the parts on a clean, soft surface. If you require any assistance with assembly, parts or information on other products, please visit our website: www.officestar.net or call or write us.




1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **FOR INDOOR RESIDENTIAL USE ONLY.**


LIMITED WARRANTY

OSP Home Furnishings™ warrants to the original purchaser that this product will be free from defects in material and workmanship as described below. OSP Home Furnishings™ will repair or replace, at its option, without charge to the original purchaser only, defective products or parts for one (1) year from the date of purchase. Replacement parts can only be supplied if parts are available. Items out of production may be unavailable. This warranty shall be effective for the applicable time period beginning from the date of purchase as shown on your original sales receipt. This warranty is your sole remedy for product defects and excludes defects due to or arising in connection with product abuse or misuse, use modification of, or attachments to the product, and products or parts not used, maintained, or installed in accordance with the company's installation, maintenance and/or applicable guidelines. There are no other warranties, express or implied, other than those specifically described, including without limitation any implied warranty of merchantability or of fitness for a particular purpose. OSP Home Furnishings™ will not be responsible for incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Our quality standards are among the highest in the industry. Sometimes, no matter how hard we try, there are times when parts are damaged or missing. Our Parts Department will do everything possible to promptly remedy the problem. Contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time. To make a warranty claim, contact Parts Department. Provide model number, proof of purchase, description of the problem and obtain return authorization. At its option OSP Home Furnishings™ will: (a) Supply compatible components of current manufacture. (b) Repair the customer's component. The customer must prepay freight on any components returned to the factory. Return freight on components still in warranty will be paid by OSP Home Furnishings™.


PARTS




(A) Left Top Panel (1 PC)




(B) Right Top Panel (1 PC)




(C) Left Side Panel (1 PC)




(D) Right Side Panel (1 PC)




(E) Right Frame (1 PC)




(F) Support (1 PC)




(G) Upper Shelf (1 PC)



(H) Lower Shelf (1 PC)




(I) Upper Divider Panel (1 PC)




(J) Lower Left Divider Panel (1 PC)


PARTS




(K) Lower Right Divider Panel (1 PC)




(L) Left Rear Panel (1 PC)




(M) Right Rear Panel (1 PC)




(N) Drawer Front Panel (1 PC)




(O) Drawer Left Side Panel (1 PC)



(P) Drawer Right Side Panel (1 PC)








(Q) Drawer Rear Panel (1 PC)




(R) Drawer Bottom Panel (1 PC)

HARDWARE LIST




NO	DRAWING	DESCRIPTION	SIZE	QUANTITY
1		Screw	#6.5 x 1/2"	12 PCS + 2 EXTRA
2		Screw	#8 x 9/16"	12 PCS + 2 EXTRA
3		Nail Screw	N/A	33 PCS + 2 EXTRA
4		Screw	Ø6 x 30mm	9 PCS + 1 EXTRA
5		Screw	#10 x 1-1/2"	10 PCS + 1 EXTRA
6		Bolt	M5 x 12mm	2 PCS
7		Bolt	M4 x 22mm	1 PC
8		Cam Screw	N/A	4 PCS + 1 EXTRA
9		Cam Screw	N/A	21 PCS + 2 EXTRA
10		Cam Screw	N/A	2 PCS
11		Small Cam Nut	N/A	4 PCS + 1 EXTRA
12		Large Cam Nut	N/A	23 PCS + 2 EXTRA
13		Wooden Dowel	N/A	26 PCS + 2 EXTRA
14		Wooden Dowel	Ø8 x 40mm	2 PCS
15		Left Drawer Rail	N/A	1 PC
16		Right Drawer Rail	N/A	1 PC
17		Left Drawer Slide	N/A	1 PC
18		Right Drawer Slide	N/A	1 PC

HARDWARE LIST


NO	DRAWING	DESCRIPTION	SIZE	QUANTITY
19		Metal Plate	N/A	3 PCS
20		Knob	N/A	1 PC
21		Sticker	N/A	5 PCS

Phillips screwdriver and hammer also needed for assembly (not provided).


CAM LOCK INSTRUCTIONS



STEP 1




STEP 2




FULLY TIGHTEN ALL CAM SCREWS (9) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 3




FULLY TIGHTEN SCREWS (1) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 4




FULLY TIGHTEN SCREWS (5) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 5




FULLY TIGHTEN CAM NUTS (12) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 6




FULLY TIGHTEN SCREWS (5) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 7




FULLY TIGHTEN SCREWS (1) AND ALL CAM SCREWS (9) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 8




FULLY TIGHTEN ALL CAM NUTS (12) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 9




FULLY TIGHTEN ALL CAM NUTS (12) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 10




FULLY TIGHTEN ALL NAIL SCREWS (3) USING HAMMER (NOT PROVIDED).

STEP 11




FULLY TIGHTEN CAM SCREWS (8) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 12




FULLY TIGHTEN CAM NUTS (11) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 13




STEP 14




FULLY TIGHTEN SCREWS (5) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 15





FULLY TIGHTEN ALL SCREWS (1) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 16




FULLY TIGHTEN SCREW (7) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 17




STEP 18




FULLY TIGHTEN SCREWS (2) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 19




FULLY TIGHTEN CAM SCREWS (10) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 20




FULLY TIGHTEN CAM NUTS (12) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 21




FULLY TIGHTEN ALL SCREWS (2 & 4) AND CAM SCREWS (9) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 22




FULLY TIGHTEN SCREWS (4) AND CAM NUTS (12) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 23




FULLY TIGHTEN SCREWS (6) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 24



STEP 25



FULLY TIGHTEN ALL SCREWS (2 & 4) USING PHILLIPS SCREWDRIVER (NOT PROVIDED).

STEP 26

