

Roku®

Plus Series
4K QLED TV

Quick Start Guide



Need help?



Setup
videos



Common
questions



Tips and
tricks

Visit go.roku.com/TV



Message & data rates may apply.




© 2022 Roku, Inc. All Rights Reserved. Roku, the Roku logo, and the purple d-pad and purple fabric tag designs are trademarks or registered trademarks of Roku, Inc.

4100000918_02

What's included



Roku Plus Series
4K QLED TV



TV stands



Wire
management clip




55"/75" model x 4 screws



65" model x 6 screws

Stand screws



Power cable
for 75"
model only



USB
charging
cable




Roku Voice
Remote Pro

What you need



Phillips head
screwdriver




Laptop or mobile
phone for activation



Internet connection

STEP 1: Set up your TV



A Prepare a surface

Put a soft covering like a blanket down onto a clean, flat surface (make sure it's larger than the TV) and place the TV on it.

B Attach the stands


Use a screwdriver and included screws to attach the stands.

C Set TV upright


Place your TV on a stable, flat surface.

Mounting your TV?

For instructions, skip these steps and visit go.roku.com/TV




STEP 2: Plug TV in and pair remote



A Connect your TV

Plug your TV into a power outlet. It should turn on automatically. If it doesn't, press the power button.



B Pair your remote

Press and hold the pairing button for 5 seconds until status light turns green and starts blinking.

Get to know your TV

Video connections

HDMI - Game consoles, DVD players

Composite - Analog devices, older game consoles

Antenna/Cable - Digital antenna, cable connection

Audio connections


HDMI eARC - AV receivers, soundbars (Recommended)

Optical (S/PDIF) - AV receivers, soundbars


Audio Out/Headphone - Wired headphones

Other connections

USB - Flash drive



STEP 3: Activate your TV



Connect to internet

Follow the instructions on your TV screen. Activate your TV by using your computer or smartphone to link a Roku account.



IMPORTANT

Roku never charges for activation support.

Need help?

For help with setup, video tutorials, and more visit go.roku.com/TV

Remote features



Hands-free voice

Just say "Hey Roku" and a command to control your streaming even faster. Play entertainment, turn your TV on, adjust the volume, control playback, and more.



Push-to-talk voice

Press and hold the voice button if you don't want to use hands-free voice.




Private listening

Plug headphones into your remote to use private listening. Your TV will mute automatically.



Lost remote finder

Say "Hey Roku, where's my remote?" or press the power button on your TV.



Frequently asked questions

Why do I need an internet connection?

You'll need an internet connection to stream your favorite channels and for automatic software updates.


Why should I enter a payment method?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

Charging your remote

Connect your remote to the USB charging cable and connect to either:

- the USB port on the back of your TV
- a wall outlet using a standard USB adaptor (like your phone charger)



The status light will stop blinking once your remote is finished charging. You'll see a message on your TV when it's time to charge again.

Note: To charge your remote while your TV is off, enable "Fast TV start" in the Power settings menu.