

HP Wallet Case



Travel in style

The HP Sprocket Wallet Case helps protect your Sprocket and keeps it on hand when you're on the go. Compatible with HP Sprocket and HP Sprocket 2-in-1 only.

Product overview

Safeguards Sprocket, stores photos

- Help protect your Sprocket on the move with a wallet case, and keep instant photos and more in the side pocket.

A colorful choice

- Match the style of your Sprocket with two color options—compatible with HP Sprocket and HP Sprocket 2-in-1 only.

Goes where you go

- With the Sprocket inside, this wallet case easily fits it into your purse or backpack so you can create 2 x 3 inch (5 x 6 cm) photos virtually anywhere.

Why to buy

The HP Sprocket Wallet Case is slim, stylish and the perfect travel companion. Easily slip it into a bag to safeguard your Sprocket on the move, and store photos in the included side pocket. Compatible with HP Sprocket and HP Sprocket 2-in-1 only.

Compatibility

HP Sprocket, HP Sprocket 2-in-1

What's in the box

1 Black wallet case

Warranty and support

HP includes a one-year limited warranty with online support available. Consult the HP Customer Support Center for details, or go to <http://www.hp.com/go/orderdocuments>. Internet access required and not included.

Additional information

HP product number	2HS23A (Black)
Product dimensions ¹	4.13 x 6.1 x 0.98 in 104.9 x 154.94 x 24.89 mm
Product Weight	0.2 lb 0.09 kg

¹ Dimensions vary as per configuration.

Learn more at hp.com