

# Chair Assembly Instructions

Your chair comes packaged in one box.

**DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.**


Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.

Estimated Assembly  
Time in Minutes

★ ☆ ☆  
<15 <45 60+

## Parts List


- A** 1 x Chair
- \* **B** 2 x Front Legs
- \* **C** 2 x Back Legs
- \* **D** 4 x Washers
- \* Replaceable Parts



## Watch The Video




[https://youtu.be/IMqsigF\\_mWg](https://youtu.be/IMqsigF_mWg)




## Assembly

### Step 1




### Step 2

#### OPTIONAL



Adjust each leg by inserting a washer (D) to make it even and level with the floor.



Foam in the arm may be compressed during shipping. Gently knead the affected area. The foam will fully expand within 24-48 hours. Repeat if necessary.

Your style may differ from images. Care for your furniture by periodically tightening all legs.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

**CAUTION:** Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531  
Mon-Fri 8:00am - 4:30pm CST  
[customerservice@furniturequestions.com](mailto:customerservice@furniturequestions.com)