


User Manual



- Thank you for purchasing this product! To ensure proper understanding and installation, please read this manual carefully.
- 42001 r20251203

Table of Contents

1、 Safety Precautions Before Fan Installation-----	1
2、 Parts Checklist-----	2
3、 Installing the Hanging Bracket-----	3
4、 Installing the Downrod, and Adapter cover-----	4
5、 Installing the Blades-----	6
6、 Installing the Canopy-----	7
7、 Installing the Fan Body-----	8
8、 Installing the Cap-----	9
9、 Remote Control Instructions-----	10

WARNING!



Warning
High Voltage Hazard: Do not open the rear cover unless you are a qualified technician!



Warning: Electric Shock Hazard. Keep closing.
Prevent Electric Shock: Do not open the cover. No user-serviceable parts inside. Consult a professional for servicing.



This unit contains uninsulated high-voltage components. To avoid electric shock, do not remove the cover or rear panel unless you are a qualified technician.



Some parts are marked for safety. Replace components only with original specifications. This unit contains no user-serviceable parts. For repairs, contact authorized personnel.


1、 Safety Precautions for Ceiling Fan Installation




This fan must be installed by a manufacturer-approved or qualified professional. Do not attempt self-installation.

- 1) Turn off the power before installation or disassembly.
Follow the sequence:
Installation: Ground wire → Neutral wire → Live wire.
Disassembly: Live wire → Neutral wire → Ground wire.
- 2) Ensure all screws are securely tightened when installing the fan.
- 3) Keep all objects away from rotating blades during operation.
- 4) Maintain a minimum clearance of 2.3m from the floor and 80cm from walls to avoid injury.


2、Parts Checklist



① Hanging bracket




② Long Downrod
Short Downrod



③ Canopy



④ Adapter Cover



⑤ Motor




⑥ Cap




⑦ Blade x8




⑧ Blade Iron x8




⑨ Blade Medallion x8




⑩ Hardware kit



⑪ Remote Components
(Including The Back Frame)



⑫ Canopy Cover



⑬ Balance kit





**Verify all parts in this list. Contact customer service if missing
Images are for reference only.**

3、 Installing the Hanging Bracket



For Wooden Ceilings:

Use wood screws to secure the bracket to a beam or joist
(minimum wood thickness: 35mm).



For Concrete Ceilings:

- 1) Drill an 8mm hole (50mm depth) with an impact drill.
- 2) Secure the bracket using expansion bolts from the kit.



Drill an 8mm hole (50mm depth) with an impact drill first, then secure the bracket using expansion bolts from the kit.




Note:

1. Use the correct screws for your ceiling type.
2. For wooden ceilings, ensure the installation area can support $\geq 30\text{kg}$ and the wood thickness is more than 35mm (no visible deformation when pulled).


4、 Installing the Downrod, and Adapter cover

- 1) Remove the pin and R-pin from the downrod. Thread the wires through the downrod.
- 2) Insert the downrod into the hole of the adapter, insert the pin through the adapter and downrod hole, then insert the R pin to the hole of the pin at the end. Tighten the 2 set screws on the adapter to secure the downrod.
- 3) Slide the adapter cover over the downrod to cover up the adapter




5、 Installing the Blade

1) Place each blade between a blade iron and medallion. Install blade screws, found in the hardware bag, to attach the medallion to the blade iron. Repeat this step for each blade.




5、 Installing the Blade

2) Use blade screws from hardware kit to attach each blade to the motor's mounting plate (ensure correct orientation). Tighten all screws.



6、 Installing the Canopy


Assemble the canopy cover and canopy to the downrod in turn.




7、Installing the Fan Body

1) Loosen and remove the M6 screw from the hanging bracket, and loosen the 2 M5 screws at the same time(loosened but not removed).As shown in Figure 1.


2) Lift the fan body, thread the lead wire and downrod through the middle holes of the hanging bracket, align the mounting hole on the side of the downrod with the mounting hole on the side of the hanging bracket, and use the M6 screws that were just removed to pass through the side holes of the downrod and the hanging bracket. Tighten the M6 screw and two M5 screws.As shown in Figure 2.



3) Insert the receiver into the hanging bracket and wire it according to the following wiring method. As shown in Figure 3.




4) Organize the wires inside the hanging bracket, first loosen the two screws at the bottom of the hanging bracket but not removed. Lift the canopy, pass the keyhole at the bottom of the canopy through the screw at the bottom of the hanging bracket, and then screw it in from right to left. Use a screwdriver to fix the two screws of the canopy tightly.As shown in Figure 4/5.




8、 Installing the Cap

Use cap screws from hardware kit to attach, tighten all screws.



9、Remote Control Instructions

FUNCTION INTRODUCTION




- ① Turn off all fans and lights
- ② Indicated light
- ③ Buzzer On/Off, press and hold this button for 3 seconds to turn on or off
- ④ 1-6 wind speeds
- ⑤ Fan off
- ⑥ Fan forward button
- ⑦ Fan reversal button
- ⑧ Natural wind
- ⑨ Timer setting: 1 hour, 2 hours, 3 hours, 4 hours, 5 hours, 8 hours

WARNING

1. In case of problems such as remote control, the first time to replace the battery attempt.
2. When the emitter cannot control the receiver, please check the battery switch touching normally or not, correction of the positive and negative, full or empty of the power.
3. Please remove the battery if not used for a long time to avoid battery aging and leakage that may damage the remote control.
4. Do not disassemble the remote control to avoid damaging the internal electronic components

WIRING SCHEMATIC DIAGRAM FOR RECEIVER



KINDLY REMINDERS

The Remote Control And Receiver Have Been Coded, when The Emitter Cannot Control The Receiver, Please Check The Battery Switch Touching Normally Or Not, Correction Of The Positive And Negative, Full Or Empty Of The Power. If Not, Please Matching The Code Again.

Code Matching Process

After the receiver is powered off for 2 minutes, turn on the power switch and hear a "beep sound. Immediately press and hold the fan button (F) for 5 seconds, hear the buzzer sound three times that the code has been successfully matched.

NOTES

1. During the installation process, the power must be cut off.
2. Do not disassemble the remote control to avoid damaging the internal electronic components
3. When the emitter cannot control the receiver, please check is there any existence of similar remote controlled products nearby, then check whether they works, because remote controlled product with the same frequency will disturb each other
4. Low battery voltage will affect the sensitivity of the emitter and the signal reception accordingly (the indicated light will flash out its warning when the battery get low voltage), must replace if the battery is getting low voltage.
5. When installing the fan, the fan ceiling cover don't press the antenna (or other wires, it is easy to breakdown the wire and short-circuited.