

Need help?

We are here for you.

Visit [www.arlo.com/support](http://www.arlo.com/support) for quick answers and:

- How-to videos
- Troubleshooting tips
- Additional support resources

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Any other trademarks are for reference purposes.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à [arlo.com/docs](http://arlo.com/docs).

(If this product is sold in Canada, you can access this document in Canadian French at [arlo.com/docs](http://arlo.com/docs).)

For regulatory compliance information including the EU Declaration of Conformity, visit [www.arlo.com/about/regulatory/](http://www.arlo.com/about/regulatory/).

March 2023

Arlo Technologies, Inc.  
2200 Faraday Avenue, Suite 150  
Carlsbad, CA 92008 USA



201-50681-03



Set up your Arlo Wire-Free Outdoor Siren

- 1 Download the latest version of the Arlo Secure App and sign in or create an account when prompted.



- 2 Make sure your Arlo Home Security System has already been installed and synced with the Arlo Secure App.

- 3 Go to the **Devices** tab and then tap the **+** icon. Select the **Security System**. Follow the instructions to add your Arlo Wire-Free Outdoor Siren.

The app will show you how to:

- Remove the tab from the batteries.
- Set up the Arlo Wire-Free Outdoor Siren and sync it with your Arlo Home Security System.
- Use the screw kit to mount the Siren.

## Arlo Wire-Free Outdoor Siren

---



(1) Arlo Wire-Free Outdoor Siren



(1) Screw Kit



(2) CR123 Batteries

## LED Behavior

---

### Situation

---

During initial set up using the Arlo Secure App

### LED Behavior

---

**Solid blue:** Powering on/start up. This can take several seconds.

**Slow blinking blue for up to 2 minutes:** The Siren is ready to pair with the Keypad Sensor Hub.

**Fast blinking blue:** Pairing is successful.

**Fast blinking amber:** Pairing has failed.

---

Using the Arlo Secure App to run a RangeFinder test

**Slow blinking blue:** The Siren is within connectivity range of the paired Keypad Sensor Hub.

**Slow blinking amber:** The Siren is out of connectivity range of the paired Keypad Sensor Hub.

---

Factory reset

To manually factory reset the Siren, press the SYNC button 5 times quickly. You will hear a beep each time you press the SYNC button confirming your action. If you remove the Siren while it's online via the Arlo Secure App, it will automatically factory reset.

The Siren must be set up again after a factory reset.

**Slow blinking amber for 5 seconds:** Factory reset is successful