

IMPORTANT

# WELCOME

## START HERE



**LOCKLY VISION™ ELITE**

Enjoy the freedom™

# FOLLOW THESE STEP-BY-STEP VIDEO INSTRUCTIONS TO INSTALL YOUR LOCKLY VISION™ ELITE



## HOW TO INSTALL




Scan to watch  
step-by-step video  
installation



FEWER FRUSTRATIONS.  
FINISH FASTER.

# DOWNLOAD THE FREE LOCKLY APP

The Lockly mobile app allows you to control and monitor all of your Lockly smart locks.



# FAQs

How to add a Fingerprint?

How to do a factory reset?

Locking Lockly with APP?


How to rekey a Lockly smart lock?

What to do if the Initial Code is lost?

How to Pair Lockly with the APP?

Why is my Connect Hub not working?

What's the difference between the models?



2




## WE'RE HERE TO HELP

Need Help?

Our Customer Care team is here to assist you.

Phone: (669)500-8835 or **Lockly.com/help**

# INSTALLATION OVERVIEW AND PARTS LIST



## Parts List

Labeled As	Description
A	Keys
B	Exterior Assembly
C	Exterior
D	Mounting Plate
E	Adhesive
F	PM5×60mm Screw
G	Interior Assembly
H	PM4×12MM Screw
I	Battery Cover
J	Deadbolt
K	KA4×20MM Screw
L	Strike Plate
N	Dust Box
P	Strike Spacer
R	Vision Connect
S	LAN Cable
T	Power Plug
U	TF Card
V	Activation Card
W	KM3x6mm Screw
X	Pin Key

Lockly Vision™ Elite can be fitted for both right swing doors and left swing doors.

