



Quick Setup Guide

Let's get started

Need Help?




For more help, please follow the steps below to access your Series support page:

1. Please visit:
2. **Support.NightOwlISP.com**
3. Enter **BWNIP4** into the Search bar or scan the QR Code

What's Included

Battery Wi-Fi Cameras



Battery Wi-Fi
Camera(s)



Rechargeable Batteries
(Includes 2 per Camera)





Mounting
Hardware Kit




(1) USB-C Charging
Cable

NOTE: If mounting the camera, you will need a screwdriver or drill (not included).

Battery Wi-Fi Camera Details



Camera Bottom
(With Cover)



Camera Bottom
(Without Cover)

Download the Night Owl App


If you are a first-time user, go ahead and download the Night Owl app. Quickly create an account and log in.

Already have an account? Simply log in.



Initial Start-up Steps


1. Install the batteries. Press the button on the camera's belly to release the battery cartridge and insert the batteries. Replace the cartridge and connect the USB cable to the port under the rubber piece.



NOTE: Each camera requires 2 rechargeable batteries but can hold up to 4 batteries. Use of 3rd party batteries may damage the camera and void your warranty. Compatible batteries can be purchased at NightOwlSP.com

Initial Start-up Steps (Continued)

2. Charge the camera(s) for at least 3 hours. Lift the rubber piece on the camera's belly and connect the USB cable to the camera and a USB power supply. Please ensure the batteries are installed or the camera(s) will not charge.




Placing the camera in Pairing Mode (if needed): If the camera is not in pairing mode, press the button on the camera's belly to release the battery cartridge. Press and hold the reset button for 10 seconds or until the camera says, "Camera is in Pairing Mode."

NOTE: Keep your camera plugged in for up to 3 hours to fully charge.

Connecting to a Wi-Fi Router


Adding Your Camera

1. Open the Night Owl Protect App.
2. Tap on “Add New” or “+”
3. Follow the on-screen instructions to complete the setup process.



iOS

For iOS Tap
“Add New.”



Android

For Android
Tap “+”

Connecting to a Wi-Fi Router (Continued)

Setup Using: QR Code (Recommended), Network Discovery, Manual by S/N.




Once the QR Code is captured the App leads you through the rest of the process.

Camera Installation (Continued)

If setup is completed using Network Discovery or Manual setup by UID once your device is added to the network you will need to select the category of the device to proceed.

Select "Standalone camera" from the device list



NOTE: The Router's security protocol MUST be set to WPA/WPA2 (strong security).

Add Your Camera


To begin viewing your camera, add it to the Night Owl app or to a compatible recorder.

For more detailed setup steps, please scan the QR code below.




Camera Installation

1. Use the holes in the back of each camera as a template to mark the screw positions on the surface where you plan to mount the camera.



2. Using a drill bit slightly smaller than the included screw anchors, drill into the mounting surface using the guide marks.
3. Insert the screw anchors. Line up the camera base holes with the screw anchors, insert the screws through the base and tighten to secure the camera in place.



FCC RADIATION NORM

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Compliance Statement These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed or used in accordance with the instructions, may cause harmful interference to radio communication.

However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on. The user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION!

The Federal Communications Commission warns the user that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment should be installed and operated with a minimum distance of 8 inches between the radiator and your body.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

*RF warning for Mobile device:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. A distance between the surrounding area and the top surface of the device is greater than 20cm.

Night Owl SP LLC

Night Owl
4851 Tamiami Trail N, Suite 200
Naples, FL 34104
(866) 390-1303

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

QSG-BWNIP4 4-250916