




INSIGNIA

QUICK SETUP GUIDE


41-in. 6-Drawer Tool Chest

NS-41TC6DB18



41-in. 10-Drawer Rolling Tool Cabinet

NS-41RTC10DB18



The tool chest and rolling tool cabinet are sold separately.

Before using your new product, please read these instructions to prevent any damage.



V1
FINAL
FOR PRINT


Final flat size: 23 × 8 in. (584.2 × 203.2 mm)
Folded size: 5.75 x 8 in. (146.0 x 203.2 mm)

TOOL CHEST PACKAGE CONTENTS

- Tool chest
- Plastic feet (4)
- Lock key (taped to top of chest)

ATTACHING THE PLASTIC FEET (OPTIONAL)

Insert all of the plastic feet into the holes on the bottom of the tool chest.



USING THE RUBBER GROMMETS AND POWER STRIP


- 1 Plug the chest's power cord into a power outlet.
- 2 Push your device's power cord through one of the rubber grommets from the rear of the chest.

Note: The bottom-left rubber grommet is only for the chest's power cord. Do not push your device's power cord into this grommet.

- 3 Make sure that you push extra cord through the rubber grommet, then plug your device's cord into the integrated power strip.

- 4 Pull the extra cord length out through the rear of the chest, ensuring that the weather-resistant rubber flaps are pointing out of the tool chest.

Note: Do not push the cord through the rubber grommet from inside the tool chest, as it will expose the integrated power strip to the environment.



SPECIFICATIONS

- Chest dimensions (H×W×D): 23.0 × 40.7 × 17.7 in. (58.5 × 103.3 × 45 cm)
- Chest weight: 108.5 lbs. (49.2 kg)
- Maximum weight per drawer: 100 lbs. (45.4 kg)
- Maximum weight limit (including contents): 600 lbs. (272.0 kg.)
- Power Strip AC output: 125VAC~60Hz 15A
- Power Strip USB ports output: 5 VDC (each) / 2.1A (combined)
- Power Strip cord length: 6 ft (1.8 m)
- Max Temp: 60°C 14 AWG (3x 2.08 mm)

ROLLING TOOL CABINET PACKAGE CONTENTS

- | | |
|--------------------------------------|----------------------|
| • Tool cabinet | • Fixed casters (2) |
| • Cabinet handle | • Swivel casters (2) |
| • Wrench | • M8 × 25 bolts (16) |
| • Lock key (taped to top of cabinet) | • M6 × 16 bolts (4) |
- Anti-tip hardware:
- Brackets (2)
 - Connector plates (2)
 - ST6.3 x 65L screws (2)
 - M6 x 16L screws (6)
 - Steel Cable (2)

ASSEMBLING THE HANDLE AND CASTERS

Notes:


- Two people are recommended for assembly.
- Assemble your cabinet close to the final intended location. The product is heavy and may be difficult to move after assembly.

HANDLE

- 1 Position the cabinet handle over the holes on the side of the cabinet.
- 2 Use the included wrench or a 10 mm wrench or socket to attach the handle with the included M6 × 16 bolts (4).

Note:

- The holes in the cabinet are tapped and do not require nuts.




CASTERS

- 1 Lock the drawers on the cabinet, then lay the cabinet on its top. Use the packaging to protect the finish on the cabinet.
- 2 Use the included wrench or a 12 mm wrench or socket to attach the swivel casters (2) on the same side as the handle with the included M8 × 25 bolts (8).
- 3 Repeat the previous step to attach the fixed casters (2) to the other side of the cabinet.
- 4 Return the cabinet to its upright position.

Notes:

- Do not overtighten the bolts.
- Grease the casters annually using high-quality bearing grease.



SPECIFICATIONS

- Cabinet dimensions (H×W×D): 42.4 × 44.2 × 18.0 in. (107.9 × 112.2 × 45.8 cm)
- Cabinet weight: 189.2 lbs. (85.8 kg)
- Maximum weight per drawer: 100.0 lbs. (45.4 kg)
- Maximum supported weight: 1200 lbs. (544.2 kg)




COMBINING THE CHEST AND CABINET

Tools Needed: A Phillips screwdriver

- 1 Lift the chest onto the cabinet.

Notes:

- Two people are recommended for lifting the chest.
 - The chest can be combined with the cabinet even if the plastic feet are attached to the chest.
- 2 From the anti-tip hardware, use M6 × 16L screws (4) and a Phillips screwdriver to install the brackets (2) onto the back of the cabinet and chest. Tighten all screws securely.



Two people are recommended for lifting the chest.

SPECIFICATIONS (COMBINED)

- Dimensions (H×W×D): 65.1 x 44.2 x 18.0 in. (165.3 x 112.2 x 45.8 cm)
- Weight: 297.6 lbs. (135.0 kg)
- Maximum weight limit (for cabinets stacked together) is 1200 lbs.






SECURING YOUR CABINET AND CHEST TO A WOODEN WALL STUD

Tools Needed

- A Phillips screwdriver
- A drill with a 1/8" drill bit

Note: These instructions are only meant for wooden wall studs. Do not secure your cabinet to any other type of surface.


- 1 Place the combined cabinet and chest at least 1" (2.5 cm) from the wall.
- 2 From the anti-tip hardware, use M6 × 16L screw and a Phillips screwdriver to install a connector plate onto the side of the cabinet.
- 3 Attach the carabiner end of the steel cable to the connector plate.
- 4 Drill a hole in the wall with a 1/8" drill bit, then push an ST6.3 × 65L screw through the other end of the steel cable and tighten the screw securely into the wall with a wrench.
- 5 Repeat Steps 2–4 on the other side of the cabinet.



REMOVING AND RE-INSERTING THE DRAWERS


REMOVING

- 1 Empty the drawer, then fully extend the drawer.
- 2 Push the release lever on the left side up, while pushing the release lever on the right side down.
- 3 Pull the drawer out.



RE-INSERTING

- 1 Extend the drawer slides.
- 2 Insert the brackets on each side of the drawer into the drawer slides. Make sure that they are positioned properly.
- 3 Close the drawer completely to set the drawer slides into their proper position.



MAINTAINING YOUR CABINET AND CHEST

- Lubricate the drawer slides semi-annually.
- Clean the drawer fronts, drawer trim, and other surfaces with a mild detergent and water periodically.
- Apply auto wax to preserve the chest's or cabinet's finish and to protect against scratches.
- Remove grease and oil with a standard, nonflammable cleaning fluid.

OBTAINING REPLACEMENT PARTS

For assistance with replacement parts, please call Insignia Customer Service at **1-877-467-4289**.

SAFETY

- Push the cabinet when moving it. Do not pull it.
- Use the caster's brakes when the cabinet is not being moved. This prevents the cabinet from rolling.
- Secure this product properly before moving it with a forklift.
- Do not attach or mount the cabinet or chest to a vehicle. This may cause personal injury or product damage, and it will void the product's warranty.
- Do not tow the cabinet with power equipment.
- Do not alter the cabinet or chest in any way. For example, do not weld external lock bars or attach electrical equipment to the cabinet or chest.
- Close the drawers completely before locking the cabinet or chest in order for the lock bars to work properly.
- Lock the drawers before moving the cabinet or chest. The drawers could open while moving and make the product tip over, which may cause personal injury or product damage.
- Do not stand on the cabinet or chest. You may fall and injure yourself.
- Be careful when opening more than one drawer. The cabinet may become unstable and tip over, which may cause personal injury or product damage.
- Keep the cabinet or chest on even surfaces. It may tip over if stored or moved on an uneven surface, which may cause personal injury or product damage.
- Be careful when closing the cover chest's cover. Remove your hands before the cover closes completely to prevent personal injury.

Extension cord:

- Follow all of the extension cord manufacturer's warnings and instructions.
- DO NOT insert the extension cord through the rear of the chest without the rubber grommets in place.
- Only use a three-wire extension cord with all three prongs intact. Never remove the round grounding prong.
- Connect the extension cord to a 125 Volt GFCI-protected outlet with proper grounding. If a GFCI outlet is not available, use an extension cord with built-in GFCI protection.
- Check the insulation and plugs of the extension cord before using. DO NOT use the cord if it is worn or damaged.
- DO NOT overload the extension cord.
- Remove the extension cord before moving or transporting the chest.
- Only use an extension cord that is rated for outdoor use.
- DO NOT connect the extension cord to an outlet that also supplies critical safety equipment with power.

Electrical shock hazard:

- Do not plug the power cord into an outlet with wet hands.
- Do not use the chest near a bathtub, a shower, or a swimming pool.
- Make sure the chest/cabinet plug matches the power outlet.
- Never modify the plug in any way.
- Use unmodified plugs and matching outlets to reduce the risk of electric shock.
- Avoid body contact with earthed or grounded surfaces. There is an increased risk of electric shock if your body is earthed or grounded.
- Make sure the power cord is unplugged before servicing or cleaning the chest.

Cordless power tool battery charging:

- See charger's manual for proper use and care of your charger and batteries.
- Follow all warnings and instructions provided with your battery charger.
- Place your chargers and electrical connections inside the till.
- Only use your chargers in a dry area. DO NOT expose your charger to liquid, vapor, or rain. If your charger gets wet, DO NOT attempt to use it. Unplug the extension cord from the power supply before handling a wet charger or cords.
- Only use chargers and batteries that are intact and operating properly.
- DO NOT touch the plug's metal prongs when plugging the charger into a power outlet
- DO NOT place or attempt to charge lead-acid batteries in the chest.

LEGAL NOTICES

FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Compliance

IC Statement

This device complies with Industry Canada's license exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
 - (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

CAN ICES-3 (B)/NMB-3(B)

Cet appareil radio est conforme au CNR-247 d'Industrie Canada. L'utilisation de ce dispositif est autorisée seulement aux deux conditions suivantes :

- (1) il ne doit pas produire de brouillage, et
 - (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.
- Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)
www.insigniaproducts.com

Made in China

