

INSIGNIA™

QUICK SETUP GUIDE

SSD Mount

NS-PCSSDM7 /
NS-PCSSDM7-C

Before using your new product,
please read these instructions to prevent any damage.

The NS-PCSSDM7 / NS-PCSSDM7-C SSD mounting bracket lets you install an SSD drive into a 3.5-inch drive bay in a desktop PC.

PACKAGE CONTENTS

- SSD drive bracket
- Screws (8)
- *Quick Setup Guide*


YOU'LL NEED

- Phillips screwdriver


INSTALLING THE SSD DRIVE IN THE DRIVE BRACKET

Note: We recommend that you use an anti-static bracelet to protect the data on the SSD drive.

- 1 Place your mounting bracket on a flat surface with the sides facing up.
- 2 Place the SSD drive (not included) on your bracket. Make sure that the screw holes on the bottom of the SSD drive align with the holes on the bottom of your bracket.



- Carefully turn the bracket and drive over.
- Insert four screws through the holes on the bottom of your bracket and into the holes in the drive, then use a Phillips screwdriver to tighten the screws.



The SSD drive is ready to install into a PC. See the documentation that came with your PC for information about installing hard drives.

Note: Use the extra screws to secure the sides of your bracket to the PC drive bay.

SPECIFICATIONS

Dimensions (L × W × H): 3.9 × 4.0 × 0.46 in.
(100 × 101.5 × 11.6 mm)

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289
www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2017 Best Buy. All rights reserved.
Made in Taiwan