

ZERO DARK

SOLAR POWERED PATHWAY LIGHTS



INSTRUCTIONS

1. It is normal that solar lights may turn on or off at slightly different time from one another as their sensors may detect the sunlight strength differently from their individual locations.
2. Solar panel surface must be kept clean to collect sunlight effectively.
4. The LED bulb installed inside the solar light normally lasts over 100,000 hours.

HOW TO USE:

1. Push the spike securely into the ground.
2. Secure the stake onto the spike.
3. Secure the solar light onto the stake.

WARNING:

- Do not use a hammer. If the ground is hard, use water to soften.
- Do not press down on the solar panel on top of the solar top housing. This can damage the light.