

BEVERAGE REFRIGERATOR

USER MANUAL



Thanks for choosing our beverage refrigerator.

Please read this manual carefully and make sure to keep this manual in the place accessible by a user at anytime.

USER MANUAL

Please read the following instructions carefully before using your beverage refrigerator.

-Wrap all food items with a plastic protection film to avoid dehydration and loose food flavor.

-Close immediately the glass door after each usage.

-If you don't use the refrigerator for a long period of time, please disconnect the unit, clean the inside parts, put the beverage refrigerator in a dry area and leave the doors lightly open.

1. GENERAL

The beverage refrigerator is used in places such as hotels, offices, houses and student dormitories. It is mostly suitable for refrigerating and conserving foods such as fruits and beverages. It enjoys the advantages of small size, light weight, high efficiency and low energy consumption.

2. UNPACKING REPACKING AND MOVING

◆ Unpacking

Just cut the tape of carton, and then take off the carton.

◆ Moving

Be sure refrigerator shelf in upright positions during moving it. Don't tilt for more than 45° and never upside down it.

3. INSTALLATION

◆ The refrigerator should be placed on a flat and solid top surface. It should be kept away from sunlight, heat source, humid or wet place. The beverage refrigerator should be kept away from the wall for a proper space for good.

◆ Air circulation is important when the refrigerator is placed in a cupboard, therefore the cupboard must be moved out for good air circulation.

4. OPERATION

◆ Before plug in, please check the following:

There must not be any damage on all electric cords.

Each screw must be well fixed.

Wall outlet must be properly connected.

◆ When operation for the first time

IMPORTANT: please place the freezer upright for 24 hours because the oil in the compressor needs time to settle to the bottom. If the machine is turned on right away, the oil can leak into the refrigeration system causing issue.

Before loading food in, run the refrigerator without any load until it auto stops at the desired temperature. Usually it takes 2 to 3 hours then you can set the thermostat to the required setting and put foods in.

◆ Temperature control

Refrigerator temperature can be adjusted by turning the knob of the thermostat.

Usually it's recommended to set the temp to 4-5 level. 0 is defrost mode and 7 is the coldest.

In order to maintain good cooling efficiency and save energy, we recommend you not to store too much and not to open the door too frequently.

5. DEFROST

◆ Defrost the freezing compartment when ice on the evaporator reaches 3-4 mm. When defrosting please remove out all foods first.

◆ Set the thermostat at "0" position and keep the door open. After the frost or ice melted, discard the melted water and dry up the interior of the refrigerator. The refrigerator can be restarted by a turning its thermostat to the desired setting.

CAUTION: never use any sharp of metallic instruments (e.g. knives) to remove frost or ice from the evaporator as this will damage the evaporator causing serious problems.

6. CLEANING AND MAINTENANCE

◆ To clean the refrigerator, disconnect power supply and removed foods, shelves. Use a solution mixed with 2 spoons of baking soda per litre of warm water to clean the interior. Then wipe it clean with water.

◆ Never use acids, chemical, gasoline, benzene or the like for cleaning any part of the refrigerator. Never use boiling water and benzene to clean plastic parts because they may deform or damage the plastic parts.

- ◆ Too much beverages stored in the refrigerator will affect cold air circulation, so some free space must be left. It's recommended that about 70% of storage volume is loaded.
- ◆ Don't store explosive materials such as gasoline liquefied gas in the refrigerator. Otherwise, there will be a danger of explosion caused by electric sparks.

7. SAFETY INSTURCTIONS

- ◆ Before plugging your beverage refrigerator in, check that the electric supplying must comply with the rating (voltage, frequency) of the machine, the rating plate is usually on the back of the refrigerator and should always be plugged in it to an individual electrical to prevent overload, which could cause a possible fire hazards from over heating wires.
- ◆ Don't splash water on the refrigerator as this will cause electrical leakage. If the power cord is damaged, ask one technician to replace it immediately. Our corporations will be not responsible for any accident caused by improper operation.

8. WARNINGS

- ◆ Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- ◆ The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. At disposal, please consult with service agent or similarly qualified person.
- ◆ Do not use mechanical devices or the means to accelerate the defrosting process other then those recommended by the manufacturer. Don't damage the refrigerant circuit.
- ◆ Do not use mechanical devices or the means to accelerate the defrosting process other then those recommended by the manufacturer. Don't damage the refrigerant circuit.

All the machines cover one year warranty since the date of purchase. Please feel free to contact us if there is anything we can help. Thanks.