


BT-9177 PARTS

ASSEMBLY INSTRUCTION


1)X1



(8)X5




)X1




(9)X8




(X1(L)X1(R))



(10)X2



X1



(11)X2



X1




(12)X4




(1



(13)X8




1




(14)X1




①




③




②



④



⑤



⑥

