

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Apple is a trademark of Apple Inc., registered in the US and other countries. App Store is a service mark of Apple Inc. HomeKit is a trademark of Apple Inc. To control this HomeKit-enabled accessory, the latest version of iOS or iPadOS is recommended. Google Play and the Google Play logo are trademarks of Google LLC. Any other trademarks are for reference purposes.

Use of the Works with Apple badge means that an accessory has been designed to work specifically with the technology identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à arlo.com/docs.

(If this product is sold in Canada, you can access this document in Canadian French at arlo.com/docs.)

For regulatory compliance information including the EU Declaration of Conformity and where to find e-label information for US FCC & Industry Canada, visit www.arlo.com/about/regulatory/.



Arlo Technologies Intl. Ltd.
Ground Floor, Building 3
University Technology Center
Curraheen Road, Cork, T12 EF21
Ireland

Note: To add your Arlo SmartHub to the Apple Home app, tap + and scan the HomeKit setup code.

HomeKit setup code



March 2021



201-50532-01

Arlo Technologies, Inc.
2200 Faraday Avenue, Suite 150
Carlsbad, CA 92008 USA



Set up your Ultra 2 Spotlight Camera

1. Download the Arlo app.
2. Follow the setup instructions for your SmartHub and camera.



What's in the box



Arlo SmartHub +
power adapter



Ultra 2 Spotlight Camera
with Anti-Theft Mount



Wall Plate



Screw Kit




Ethernet cable



Security Key



Rechargeable
battery




Dual Charging Station +
power adapter

Mount your camera

We recommend that you use your Dual Charging Station to fully charge the camera battery before you mount the camera.

1. Place the wall plate with the arrow pointing up and secure it with screws.

For drywall, use the provided wall anchors.




2. Insert your camera with its battery into the Anti-Theft Mount housing.

3. To attach the housing to the wall plate:
Align the small screw in the housing with the dot on the wall plate.

Turn the housing clockwise until it clicks into place.


Use the security key to tighten the small screw.



4. Adjust your camera position, then finger-tighten the mount lock (clockwise) to lock the camera in this position.



Note: To release your camera from the housing, insert the security key into the security keyhole and turn the key clockwise.



Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and:

- How-to videos
- Troubleshooting tips
- Additional support resources

Battery charging

You can use the Dual Charging Station to charge Ultra 2, Pro 4, Floodlight, and XL rechargeable batteries.

1. Connect the power adapter to the charging station.
2. Plug the power adapter into an indoor electrical outlet.
3. Insert one or two Arlo rechargeable batteries.

