

Nc9 (由我新版 新条状数显) 说明书
尺寸: 71*68mm

<div data-bbox="222 632 1215 682"> </div> <div data-bbox="222 731 1215 779"> </div> <div data-bbox="222 779 1215 829"> <p>Model No.: T11124</p> <p>Thank you for purchasing the TOZO authentic product.</p> <p>For more latest products, parts and accessories, please visit: www.tozostore.com</p> <p>For any assistance please contact Email: info@tozostore.com</p> </div> <div data-bbox="222 829 1215 885"> <div> </div> <div> <p>Scan the QR code to get the manual in other languages</p> </div> </div>	<div data-bbox="1215 632 1732 682"> <p>8.0 TOZO App</p> <p>Download the TOZO App for UI customization, EQ settings, and more.</p> <ul style="list-style-type: none"> UI customization: Most of the controls can be customized in the app. EQ settings: There are lots of EQ settings you can choose from in the app to optimize your experience while enjoying different music genres. Earbuds firmware update: The earbuds firmware can be updated in the app. <p>Once you connect the earbuds to the app, you will be informed if a new version of firmware is detected.</p> </div> <div data-bbox="1215 682 1732 731"> <p>9.0 TOZO App Pairing</p> <p>Step 1: Download the TOZO app on your phone.</p> <div> </div> </div> <div data-bbox="1215 731 1732 779"> <p>Step 2: Pair your earbuds with Bluetooth.</p> <div> </div> </div>	<div data-bbox="1732 632 2246 682"> <p>10.0 EU Battery Regulation</p> <p></p> <p>This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product shall not be treated as household waste. Instead, please separate battery(ies) from other types of waste and recycle it (them) through your local recycling system to protect environment and health. (When Cd is more than 20ppm or Pb is more than 40ppm, the chemical symbol of the excess substance shall be marked under the separate collection symbol) For more detailed information about recycling of this battery(ies), please contact your local authority or the shop where you purchased the product or battery(ies).</p> </div>	<div data-bbox="2246 632 2760 682"> <p>11.0 FCC Compliance Statements</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Cautio: Changes or modifications not expressly approved by the party responsible for compliance couldvoid the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>RF Exposure Compliance</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p> </div> <div data-bbox="2246 682 2760 731"> <p>12.0 ISED Compliance Statements</p> <p>This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:</p> <ol style="list-style-type: none"> (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. <p>L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:</p> <ol style="list-style-type: none"> (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. <p>This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.</p> <p>This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.</p> </div> <div data-bbox="2246 731 2760 779"> <p>13.0 CE-DOC</p> <p>Hereby, [Manufacturer] declares that the radio equipment type [Model No.] is in compliance with Directive 2014/53/EU.</p> <p>The full text of the EU declaration of conformity is available at the following internet address: www.tozostore.com</p> </div>	<div data-bbox="2760 632 3242 682"> <p>TOZO®</p> <p>www.tozostore.com</p> </div> <div data-bbox="2760 682 3242 885"> <p>NC9 ACTIVE NOISE CANCELLATION</p> <p>User Manual</p> </div>
---	---	--	---	---

<div><div>TOZO®</div><div>EN</div></div> <div><h3>1.0 Product Overview and Features</h3><p>The package contains TOZO NC9 earbuds preinstalled with M-size ear tips, a charging case, a USB-C cable, extra ear tips, and instructions.</p><div><div></div><div></div><div></div></div><div><div>Display Screen</div><div>USB C</div><div>Reset Button</div></div><div><div>XXS XS S M L</div><div></div></div><div><div>User Manual Quick Guide</div><div></div></div><div><div>Indicator Light/ Noise Canceling MIC</div><div></div><div>MIC</div></div><div><div>Charging Pin Pressure Relief Hole</div><div></div></div><div><div>01</div></div></div>	<div><div>TOZO®</div><div>EN</div></div> <div><h3>2.0 Wearing Guide</h3><p>Adjust the wearing angle slightly after putting on the earbuds to push them gently into the ear canal for a better fit.</p><div></div><div></div><div></div></div> <div><div>3.0 Pairing and Connectivity</div><div><p>Take out the earbuds from the charging case. They'll reconnect to the last paired device if paired before. If not paired or pairing canceled, the earbuds enter pairing mode with a slow white light blink. Search for [TOZO NC9] on your phone and connect.</p></div><div><div>4.0 Power On/Off</div><div><h4>4.1 Earbuds Auto Power On</h4><p>Open the lid, the earbuds will power on automatically.</p><h4>4.2 Earbuds Auto Power Off</h4><p>Placing the earbuds back in the charging case and close the lid will automatically power off.</p><h4>4.3 Another Method of Earbuds Power On/Off</h4><p>Tap and hold the "L" or "R" for 3 seconds; it will turn on when the earbuds power off. Tap and hold the "L" or "R" for 5 seconds; it will turn off when not playing audio. The earbuds will automatically turn off if they remain disconnected in ANC Off Mode for more than 5 minutes.</p></div><div><div>Power on Power off</div><div></div></div><div><div>02</div></div></div></div>	<div><div>TOZO®</div><div>EN</div></div> <div><h3>5.0 Operation and Controls</h3><div><div>5.1 Wearing Both Earbuds</div><div><div>L R</div><div></div><div>X2 X2 X1</div><div>Double-tap the "L" touch area to switch to the previous song. Double-tap the "R" touch area to switch to the next song. Tap the "R" touch area to play or pause music.</div></div><div><div>Hold Hold</div><div></div><div>Tap and hold the "L" to lower the volume when music playing. Tap and hold the "R" to increase the volume when music playing.</div></div><div><div>5.2 Wearing One Earbud</div><div><div>L L/R R</div><div></div><div>X2 X1 X2</div><div>Double-tap the "L" touch area to switch to the previous song. Tap the "L" or "R" touch area to play or pause music. Double-tap the "R" touch area to switch to the next song.</div></div></div></div><div><div>5.3 Calling Control</div><div><div>L R</div><div></div><div>X1 Hold X1</div><div>On an incoming call, tap the "L" or "R" touch area to answer. On an incoming call, tap and hold the "L" or "R" touch area for 2s to reject the call. During dialing, tap and hold the "L" or "R" touch area for 2s to cancel the call.</div></div><div><div>5.4 Active Noise Cancellation Control</div><div><p>The Active Noise Cancellation function is not available when using a single earbud.</p><div><div>L</div><div></div><div>X1</div><div>Tap "L" once to switch between Transparency Mode and Active Noise Cancellation Mode. Triple-tap the "L" to switch back to Normal Mode.</div></div></div><div><div>5.5 Voice Assistant</div><div><div>L/R</div><div></div><div>X3</div><div>When using both earbuds, triple-tap the "R" to wake up the voice assistant. When using single earbuds, triple-tap the "L" or "R" to wake up the voice assistant.</div></div></div><div><div>03</div></div></div></div></div>	<div><div>TOZO®</div><div>EN</div></div> <div><h3>6.0 Active Noise Cancellation Mode and Transparency Mode</h3><div><div>5.6 Reset</div><div><p>If only one earbud is working, please follow these steps:</p><ol style="list-style-type: none">Delete all [TOZO NC9] Bluetooth records on your phone and turn off Bluetooth.Put the earbuds into the charging case, close the lid, and wait for 12 seconds.Tap and hold the RESET button on the charging case for 8 seconds to complete the reset.</div><div></div></div><div><div>6.1 Active Noise Cancellation Mode</div><div><p>With Active Noise Cancellation, TOZO NC9 earbuds detect external sounds through an outward-facing microphone and counter them with anti-noise, cancelling them before they reach your ears. Additionally, an inward-facing microphone listens for unwanted internal sounds, which are also negated by the anti-noise feature.</p><div></div><div></div><div>Active Noise Cancellation</div></div></div><div><div>6.2 Normal Mode</div><div><p>Normal mode is the default mode.</p></div></div><div><div>04</div></div></div>	<div><div>TOZO®</div><div>EN</div></div> <div><h3>7.0 Charging and Battery</h3><div><div>7.1 Charging Case Indicators</div><div><ol style="list-style-type: none">Open the charging case lid or insert the earphones into the charging case, the screen will show the battery levels of both the charging case and the earbuds. The screen will turn off after 5 seconds.While charging, the battery percentage of the charging case will flash on the screen, and at the same time, it will show the earbuds' battery levels. The screen will turn off after 5 seconds.If you single-click the Reset button on the charging case, it will display the battery levels of both the charging case and the earbuds. The screen will turn off after 5 seconds.</div><div></div></div><div><div>8.3 Transparency Mode</div><div><p>Transparency Mode enhances the voice frequency band, improving awareness of your surroundings, so you can hear what's around you without removing your earbuds. Both Active Noise Cancellation and Transparency Mode work best when your TOZO NC9 fits and is worn properly.</p><div></div></div></div><div><div>05</div></div></div>	<div><div>TOZO®</div><div>EN</div></div> <div><div>06</div></div>
--	---	---	---	---	---