



Get ready for entertainment you can feel.
Roku Wireless Subwoofer



FRONT



BACK



Power cable


What you'll need



To set up, you'll need:

- A Roku Smart Soundbar or other compatible Roku audio products.
- Your Roku® remote.

Setup



1. Power up your subwoofer

- Place your subwoofer anywhere within 30 feet of your TV.
- Plug it in to a power outlet.



2. Prepare to connect

- Press and hold  for 5 seconds to get to the pairing menu.
- Select **subwoofer**.


Note: If you don't see a subwoofer option, select speaker.



3. Follow the on-screen setup

- Follow the instructions on your TV screen to connect your subwoofer and test the sound.

Place wherever you want



Wirelessly connects up to 30 feet
from your TV.

Need more help
getting started?

[go.roku.com/
subwoofer](http://go.roku.com/subwoofer)



Video
tutorials



Wireless
help

Find tips, free trials
and more.

blog.roku.com



Roku Blog



Just wait until you feel this

ROKU Wireless Subwoofer
Quick Start Guide

ROKU

© 2019 Roku, Inc. All rights reserved. ROKU and the ROKU logo
are the registered trademarks of Roku, Inc. All other logos and
trademarks herein not owned by Roku, Inc. are the property of
their respective owners.



4100000594_1