

Instruction Manual



Warning

Be sure to shut off electric supply at main switch or circuit breaker before installation. The important safeguards and instruction appearing in this manual are not meant to cover all possible conditions and situation that may occur. It must be understood that common sense, caution and care are factors which cannot be built into any product, these factors must be supplied by the person(s) caring for and operating the unit. No responsibility will be accepted for any damage which may occur during transport or by improper installation or voltage fluctuation or if any portion of the product has been altered or modified.

Caution

- Improper installation may result in the risk of fire, electric shock, or injury to persons.
- 2. To prevent risk of fire and electric shock, do not use the unit near windows.
- Power plug must be removed from power socket before cleaning, servicing, maintence and when moving from one location to another.
- The fan should be placed on a flat and stable surface when operating to avoid overturning.
- The fan should not be placed in a damp place or where humidity is high (such as in a bathroom).

READ AND SAVE THIS INSTRUCTION

Parts Description

Operating instructions

- 1) Plug the power cord into a suitable socket.
- The fan is switched on using the rotating switch on the control board, i.e.
 O = Off, 1 = Low Speed, 2 = High Speed.

Special Attention

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- 3. Cleaning and user maintenance shall not be made by children without supervision.
- 4. Children should be supervised to ensure that they do not play with the appliance
- Ensure that the fan is switched off from the supply mains before removing the guard.