

# QUICK START GUIDE

## Box Contents



- 1 UltraVision Pet Combo™
- 2 Charging Station
- 3 Charging Bed
- 4 Spare Dust Bag
- 5 Bristled Main Brush
- 6 Side Brush (2)
- 7 Mop Attachment (2)
- 8 Microfiber Mop (2)
- 9 Heavy-Duty Mop (2)
- 10 Filter
- 11 Cleaning Tool
- 12 Warranty Card
- 13 Owner's Manual

## Getting Started


Scan code for a Video Guide



### 1 Prepare UltraVision Pet Combo's charging station

Mount the charging station on the charging bed by lining up the bed's pins with the station's sockets.

Place the charging station on a hard, flat surface, away from edges and stairs, with plenty of room around it. Plug it into the nearest outlet.



### 2 Prepare UltraVision Pet Combo for his first clean


Remove protective pieces, invisible film, and stickers from UltraVision and the charging station.

Place the side brush over the empty socket on UltraVision. Press down to lock in place.

Press and hold the **GO!** button until the screen lights up and UltraVision powers ON.

Press the **CHARGE** button to send UltraVision to dock at his station.

Or charge UltraVision manually by carefully aligning the metal nodes on the bot's back with the station's charging plates.



## bObsweep App

Scan code for a Video Guide



### 3 Prepare for Wi-Fi connection

Make sure your phone is connected to a 2.4 GHz Wi-Fi network.

On your phone, turn on:

- **Bluetooth**
- **Location Services**

And turn off:

- **Wi-Fi Calling**

Bring UltraVision and your phone into the same room as the router or modem.



### 4 Connect UltraVision Pet Combo to Wi-Fi

Download the bObsweep app on the App Store or Google Play.



Create an account and log in to the app.

When prompted, allow:

- **Location access**
- **Find nearby devices**
- **Local network permission**

If using Alexa, enable the bObsweep skill on the Alexa app.

To begin pairing, open the bObsweep app and on the Home page, click 'Add Bot.' Select **UltraVision Pet Combo** from the list of models and follow the instructions to connect to Wi-Fi.



## Quick Tips



Scan code for a Video Guide



Self-empty

Map

### \* Self-emptying

By default, every time UltraVision docks, a short but loud vacuuming process empties his dustbin into the station's dust bag.



Adjust the self-emptying frequency in the bObsweep app, keeping in mind that if the dustbin becomes too full, its contents may not be emptied properly. If you haven't vacuumed recently, set more frequent self-empties to prevent the bin from getting too packed, ensuring proper airflow.

### \* Mapping

UltraVision constantly updates his Active Map while he cleans. You can save this map.

UltraVision can store up to 3 saved maps for 3 different floors or environments.

Tap on any saved map to make it the Active Map for UltraVision to use.

Before taking UltraVision to a new floor:

- Save the map of the current floor.
- Delete the Active Map.
- Send UltraVision to map the new floor.
- Save the map of the new floor.

If UltraVision doesn't cover the entire floor in one charge, go to Settings and enable Auto-Resume. UltraVision will resume where he left off after charging.

For more support videos go to:  
[www.bobsweep.com/ultravision-pet-combo-support](http://www.bobsweep.com/ultravision-pet-combo-support)

