


# Pet Grooming Vacuum

**Model: LM5**



# Contents

---

---

<b>Safety Warning</b>	<b>01</b>
<b>Use Precautions</b>	<b>02</b>
<b>Package List</b>	<b>03</b>
<b>Product Overview</b>	<b>04</b>
<b>Product Technical Parameters</b>	<b>04</b>
<b>Operation Instructions</b>	<b>05</b>
Install the Dust Cup	05
Ready to Use	05
<b>Use of Different Accessories</b>	<b>07</b>
Accessory and Power Mode	09
<b>Maintenance</b>	<b>10</b>
How to Clean Dust Cup	10
How to Clean HEPA	11
How to Clean the Sponge Filter	11
<b>QA</b>	<b>12</b>
<b>Contact Us</b>	<b>13</b>
<b>GPSR Product Information</b>	<b>14</b>

# Safety Warning

---

- Read Before Use: Before using the pet grooming vacuum, read all safety and operating instructions.
- Supervision: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Cord Management: If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**
- Do not use to suck up water (for vacuum cleaners only).
- Please do not disassemble the product, the wrong assembly method may cause electric shock or fire. Please contact our company if maintenance is needed.
- Do not immerse in water for cleaning.
- The hose should be checked regularly and must not be used if damaged.
- Please keep the dust cup and filter clean.
- The appliance is only to be used with the power supply unit provided with the appliance.
- The plug must be removed from the socket-outlet before cleaning or maintaining the appliance.
- Please do not inhale flammable or combustible liquids such as gas o-line; In addition, please do not use the machine in or near an environment with flammable or combustible gases.
- Do not use it while smoking or working with other high-temperature items (matches, hot ash, etc.).
- Please do not put things into the opening or block the opening. Please unplug the power cord when you need to change the parts or conduct maintenance.
- Please do not use or keep it outdoors or in other wet places. Please do not use products with fragrance as the fragrance may contain flammable chemicals.

## Use Precautions


---

- Please do not operate with wet hands or unplug the power cord to avoid failure and electric shock.
- Please do not smoke or use other flammable material.
- Please do not use the machine in or near an environment with flammable or combustible gases.
- There may be a strange smell during the first use; however, it will not cause adverse effects on the body.
- When using this product for the first time, it will smell, but it will disappear after a while. Please understand, however, that if the scorching smell persists, stop using it immediately!
- Please keep the dust cup and filter clean; if the dust cup and filter are used while dirty, they may cause failure, and unexpected accidents may occur.
- During maintenance, turn off the power supply and unplug the power cord before proceeding.
- If the power is turned on for maintenance, it will cause electric shock, unexpected accidents, or injury.
- The product will stop working when the temperature rises abnormally; in case of abnormal heating of the motor, stop using it immediately. If the suction opening is blocked, please stop using it immediately. Take out the dust cup and clean the inlet and filter, then open it again after 60 minutes.
- Please be sure to install and use the filter; if you remove the filter, it will lead to failure.


# Package List

---

---



Main Vacuum Machine x 1




Hose x 1



Crevice Tool x 1



Cleaning Brush x 1





Deshedding  
Brush x 1



Grooming  
Brush x 1

# Product Overview

---



# Product Technical Parameters


---

Input	US 110V~130V~60Hz / UK 220V~240V~50HZ
Power	300W
Hose Length	1.5M
Dust Cup Capacity	1.5L
Product Size	302X220X130MM
Wire Length	2.5M
Maximum Noise	60dB


# Operation Instructions

---

## 1. Install the Dust Cup



1. Align the snap-fit.



2. Press the dust cup down by your hand.





### NOTE


If the device has no suction or is very noisy, please reinstall the dust cup.

## 2. Ready to Use


1. Connect the accessory to the vacuum cleaner through the hose.




2. Insert the plug into the socket.



3. Turn on the switch and begin vacuuming.




4. Select the speed you need. We suggest starting with silence mode for first-time use.




  
Speed  
Control Button

5. Grooming Your Pet.



6. The hair you collect can go straight into the trash.



 **NOTE**

There are 3 Cleaning Modes: Silence Mode, Standard Mode, and Max Mode.


We suggest starting with the Silence Mode for first-time use as your pet will slowly get used to the noise.

# Use of Different Accessories

---


## 1. Daily Grooming Brush

Used to clean floating hair and dander, making the hair more healthy, shiny, and soft.



## 2. De-shedding Brush

Used to remove the pet's long and unnecessary thick hair.




### ⚠ NOTE

During use, pay attention to the cutting edge and position, do not use excessive force as it causes skin irritation.


### 3. Cleaning Brush

Used to clean pet's paws or pet hair on clothes and furniture.



### 4. Crevice Tool

Used to clean hair on the furniture and or hard-to-reach areas.



## Accessory and Power Mode

- The following chart is for advice only, please choose accessories and modes according to your needs!



Accessory	Power Mode		
	Silence Mode	Standard Mode	Max Mode
	Cleans fallen hair from the sofa, corner, or other hard-to-reach areas.	Cleans the fallen hair from the sofa, corner, or other hard-to-reach areas.	Deep cleaning of stubborn dust. (A little noisy, but recommended)
	Cleans surface dust and makes the hair smooth.	Airflow massage makes the hair glossy. (Recommended)	Deep cleaning to remove dead hair. (A little noisy)
	Soft suction power to clean the pet hair on clothes.	Deep clean hair on your clothes.	Strong suction power. (A little noisy, but recommended)
	Remove loose hair.	With soft suction to de-shed pet hair.	Suction to de-shed pet hair. (A little noisy)

# Care and Maintenance



---

## Cleaning the Dust Cup


1. Press the remove button and take off the dust cup.



2. Press the release button and pour out the hair.




3. Assemble the dust cup according to the arrow direction.




- If the removed dust cup is cleaned with water or a wet cloth, be sure to install it after the dust cup is completely dry. Otherwise, it will damage the motor.
- **Please take dust cup lightly, if it drops will be damaged easily,** if you have any problems with the cup, please contact us on Amazon or contact us email: [support@oneisall.com](mailto:support@oneisall.com)

## Cleaning the HEPA & Sponge Filter


1. Remove the dust cup and remove the HEPA & sponge filter.



2. Tap it or clean it with brush. Don't wash it with water.



3. Place the HEPA & sponge filter back into the machine.



## NOTE

The product is equipped with voltage protection device. If you hear a "didi" sound when you press the switch, and the gear lights are all flashing, it means that the machine voltage is not consistent. Please check your voltage. If you have any problems, please contact us at any time with our email

**support@oneisall.com**

## Troubleshooting

Problems	Possible Causes	Solutions
Cannot be turned on	Plug not been inserted well	Reinsert the plug
	Switch not been turned on	Press switch buttonto turn it on
Weak suction	Flexible hose is clogged	Clean flexible hose and suction mouth
	Dust cup is too full	Empty dust cup
	Filter is dirty	Clean filter
The hose is broken	Accidental damage	The hose is detachable and can be stored in the bag we provided
	Bitten by pets at home	
Whistle-like noise when the machine is running	The Dust Cup snap is not aligned	Please check whether the Dust Cup is installed

- If the above solutions do not solve the problem, please stop using the product, and contact our customer support: **support@oneisall.com**

# Contact Us

---

## WE ARE READY TO HELP

oneisall offers a standard 2-year warranty. If you have any issues with your oneisall product, please do not hesitate to contact us. Be sure to include your proof of purchase, model number, and any relevant photos or videos in your message to expedite the process. Our oneisall support team is available 7 days a week and will respond to your inquiry within 24 hours. Thank you for choosing oneisall.

Please note that the oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty also does not cover consumable parts such as blades, guards, filters, brushes, and similar items. These parts may require regular replacement or maintenance.

✉ [support@oneisall.com](mailto:support@oneisall.com)

🕒 +1 877-522-8578 **(US)** Mon-Fri 8am-5pm **(PST)**

🌐 [www.oneisall.com](http://www.oneisall.com)



@Oneisall Official

# GPSR Product Information

---



Name : Apex CE Specialists GmbH  
Add : Grafenberger Allee 277-287,40237 Düsseldorf,DE  
Contact Person: Wells Yan  
Tel: +353212066339  
E-Mail: Info@apex-ce.de



Name: APEX CE SPECIALISTS LIMITED  
Add: 6f East Union Street, Manchester, England, M16 9AE  
Contact: Wells  
Tel: +441616371080  
E-Mail: Info@apex-ce.com

## GPSR-Manufacturer info:

Business Name: Shenzhenbenfendianzishangwuyouxiangongsi  
Manufacturer's address: CN, 518000, GuangDong Sheng, Shenzhen, Longhua District, Minxin Community Bishui Longting Building 6 Unit, 7B  
Tel: +86 185 6587 6424  
E-Mail: topservice4u@hotmail.com

Product Name: Pet Grooming Vacuum  
Brand: oneisall  
Product Model: LM5  
Input: US 110V~130V~60Hz / UK 220V~240V~50HZ  
Power: 300W

## FCC Statement:

---

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.



Made in China



Any problems you have, please contact us :  
[support@oneisall.com](mailto:support@oneisall.com)



Scan the QR-Code to get the product  
installation video and join us to get  
more prize