
VISIT OUR SUPPORT PAGE AND REGISTER YOUR PURCHASE TO RECEIVE AN ADDITIONAL 1-YEAR EXTENDED WARRANTY





EMAIL: SUPPORT@FUNCTION101.COM

Button Remote for Apple TV Bluetooth Edition Quick Set-Up Guide

The Button Remote for Apple TV Bluetooth Edition Is a hybrid Infrared and Bluetooth Remote. If you have a line of sight with your Apple TV it will connect out of the box.

Pairing Bluetooth Button Remote with your Apple TV

1 - Go to Settings App on your Apple TV. If you do not have a line of sight with your Apple TV, use your existing Siri Remote or iPhone Remote App to navigate to the Apple TV.

2 - In Settings, select Remotes and Devices.

3 - Select Bluetooth In the Remotes and Devices.

4 - Press the OK and MUTE Buttons at the same time for 5 seconds on your Button Remote. This makes the Button Remote a discoverable Bluetooth device on your Apple TV.

5 - Select FUNCTION101 RC located under OTHER DEVICES.

6 - A Bluetooth Pairing Request will appear on your screen and display "FUNCTION101 RC would like to pair with your Apple TV."

7 - Select Pair.

8 - Congratulations! Your Button Remote Is now connected by Bluetooth to control your Apple TV.

> For FAQs, visit our support page or email us at: support@function101.com

Programming the Volume, Mute, and Power of your TV with the Button Remote

Set-Up Mode on the Button Remote

1- Enter Set-Up Mode on your Button Remote by pressing the Menu and OK buttons at the same time for 3 seconds.

2 - The LED at the top of the remote becomes solid red. The Button Remote Is now in Set Up Mode.

Note If you have a Samsung TV, the volume, mute, and power are programmed out of the box.

<u>Programming, the TV Volume, Mute, and Power</u> 1 - HINT: In Set-Up Mode, look for the volume indicator to display on your TV during setup. This means your Button Remote has found your TV brand and they are communicating.

2 - For TV models other than Samsung, press the P-UP Button every 2-3 seconds until the volume indicator appears on your TV screen. The P-UP Button scans for the top 20 TV brands.

3 - If your volume indicator does not appear using the P-UP Button, press the P-DOWN Button every 2-3 seconds until the TV's volume indicator appears on your screen. This scans over 100 additional TV brands.

4 - When your device volume displays on your screen, test the volume up and down on the left side of the Button Remote to make it works properly, then press the OK Button.

5- Congratulations! Your Button Remote is now ready to control the volume, mute, and power of your TV!

For detailed step-by-step instructions and FAQs, visit our support page or email us at:

support@function101.com

Programming the Volume, Mute, and Power of your soundbar or receiver with the Button Remote

1 - Enter Set Up Mode on your Button Remote by pressing the Menu and OK buttons at the same time for 3 seconds.

2 - The LED at the top of the remote becomes solid red.

3 - When programming your soundbar/receiver volume, mute, and power, look for the volume indicator to appear on the receiver/soundbar display screen or LED during setup. This means your Button Remote and your audio device are communicating.

Programming the soundbar/receiver

 Press the UP Navigation Arrow (located above the OK Button) every 2-3 seconds until the volume indicator appears on your device display screen. The UP Button scans for the top 20 Audio brands.

3 - If your volume indicator does not appear, press the DOWN Navigation Arrow Button every 2-3 seconds until the volume indicator appears on your device display. This scans over 100 additional audio brands.

4 - Once your device volume displays on your device screen, test the volume up and down to make it works properly, then press the **OK Button** on your Button Remote for Apple TV.

5- Congratulations! Your Button Remote is now ready to control the volume, mute, and power of your receiver/soundbar.

For detailed step-by-step instructions and FAQs, visit our support page or email us at:

support@function101.com

RECEIVE 20% OFF YOUR NEXT ORDER ON

FUNCTION101.COM

USE PROMO CODE REMOTE20 AT CHECKOUT