



DX-BC4AA

Battery Charger with Four AA 1300mAh NiMH Batteries

Package contents

- Battery charger
- Four AA NiMH batteries
- *Quick Setup Guide*

Charging the battery

Note: Do not charge non-rechargeable batteries.

- 1** Insert two or four AA rechargeable Ni-MH batteries (included) into the battery compartment. Your battery charger can also charge AAA batteries (not included), which can be purchased separately.
- 2** Make sure that the polarity is correct (+ and -), as indicated in the battery compartment.

Before using your new product, please read these instructions to prevent any damage.

- 3** Plug the charger into any available wall outlet. The built-in switching power supply adjusts automatically. When using overseas, a plug adaptor may be required (not supplied). The red LED lights when the batteries are charging. When the batteries are fully charged (up to 12.5 hours), the charger switches off and the LED turns off.
- 4** Remove the batteries and unplug the charger.

Specifications

- Input: 110-127V AC 60Hz 4W
- Output:
 - AA: 2 × 2.8VDC 200mA
 - AAA: 2 × 2.8VDC 100mA

Charging time

Batteries can take from 8 to 12.5 hours to charge.

Note: Charging time depends on battery size and capacity.

TYPE	CAPACITY	CHARGING TIME
AA	1300-1700mAh	7-9.5 hours
	1800-2200mAh	10-12 hours
	2300-2400mAh	12.5 hours
AAA	600-800mAh	8-10 hours
	900-1000mAh	12.5 hours

IMPORTANT SAFETY INSTRUCTIONS:

1 SAVE THESE INSTRUCTIONS. DANGER-TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

- 2 For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet.
- 3 This charger is intended for use with Nickel Metal-Hydride rechargeable batteries only. Attempting to charge other types of batteries may cause personal injury and damage to the charger.
- 4 Do not expose charger to rain or moisture. For indoor use only.
- 5 Never use an extension cord or any attachment not recommended by manufacturer, otherwise this may result in a risk of fire, electric shock, or injury to persons.
- 6 Do not operate the charger if it has been subjected to shock or damage. Take it to a qualified serviceman for repair.
- 7 Do not disassemble the charger. Incorrect reassemble may result in a risk of electric shock or fire.
- 8 Unplug the charger from the outlet before attempting any maintenance of cleaning. Use a damp cloth to clean the surface. Do not immerse into water.
- 9 The appliance is not intended for use by children or infirm persons without supervision. Children should be supervised to ensure that they do not play with the appliance.
- 10 This power unit is intended to be correctly orientated in a vertical or floor mount position.
- 11 Before scrapping your charger, remove the batteries from the unit and dispose of them safely.
- 12 Don't charge non-rechargeable batteries.

Legal notices

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

One-year limited warranty

Visit www.dynexproducts.com for details.

Contact Dynex:

For customer service, call 800-305-2204 (U.S. and Canada) or 01-800-926-3020 (Mexico)

www.dynexproducts.com

DYNEX is a trademark of Best Buy and its affiliated companies.
Registered in some countries. Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2014 Best Buy. All rights reserved.
Made in China