

INSIGNIA™

## QUICK SETUP GUIDE

# 10 Watt Qi Charging Phone Stand

NS-MWPC10KS

## PACKAGE CONTENTS

- 10 W Qi Charging Phone Stand
- 3 ft. (0.9 m) charging cable
- USB wall adapter
- Quick Setup Guide


## COMPATIBILITY

Qi-enabled devices up to 10 W. Any Qi-compatible smartphones.

## FEATURES


- Angled stand displays your screen while charging
- 10 W output fast charges Qi-compatible smartphones
- Rubber pads keep your phone secure and the base from sliding
- Status LED shows when your device is charging
- Ideal for your nightstand, desk, or table

## PRODUCT OVERVIEW



## USING YOUR CHARGING PAD

- 1** Plug one end of the USB cable into the Micro USB port on the back of your charging pad.
- 2** Plug the other end of the USB cable into a USB wall charger.



- 3** Place your Qi-enabled device on the center of your charging pad with the screen facing up. The LED is blue when your device is charging.  
**Note:** If the LED is red, your device is not charging. See "Troubleshooting" for more information.

## LED INDICATOR STATUS

LED	STATUS
Blinking blue	Standby
Solid blue	Charging
Solid purple	Quick charging
Solid red	Insufficient input power
Blinking red	Charging error

## TROUBLESHOOTING

### Device not charging/LED is red

- Make sure that your device is Qi-enabled.
- Make sure that your charging pad is connected to a working power outlet.
- Make sure that your device is positioned correctly on your charging pad.
- Make sure that there are no other objects on the charging pad.
- Remove your device's case. It may be blocking the wireless signal.

### Device charges slowly

- Your device may charge more slowly with the charging pad than a charging cable. This is normal behavior.
- Make sure that your device is positioned in the center of your charging pad.

**CAUTION:** Only use the cable with the wall charger that came with your charger. Using a different cable and wall charger can decrease charging performance or damage your charger.

## SPECIFICATIONS

### Qi Wireless Charging Pad:

Input: DC 5-12V 2A max.

Output: 10 W max.

Dimensions (H × W × D): 4.4 × 3.1 × 3.1 in. (112.6 × 80 × 80 mm)

### AC power adapter:

Input: 100 -240 V ~ 50/60 Hz .45 A

Output: DC 5V/3 A, 9V/2 A, 12V/1.5 A

### Charging cable: 3 ft. (0.9 m)

## LEGAL NOTICES

### FCC Information

**FCC Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC Statement:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC statement:** This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## SAFETY INFORMATION

- Avoid dropping.
- Do not disassemble.
- Do not place metal objects between devices and the wireless charging pads.
- Thick protective case (≥ .2 in. [5 mm]) or a case that includes a magnet or metallic material, may not allow proper charging function.
- Keep wireless charging pad away from any liquid or moisture.
- The maximum ambient temperature during use of this product must not exceed 113° F (45° C).
- Do not place this device in fire or other excessively hot environments.
- Must use provided adapter for proper function, if not it may be malfunction.

## ONE-YEAR LIMITED WARRANTY

Visit [www.insigniaproducts.com](http://www.insigniaproducts.com) for details.

## CONTACT INSIGNIA:

For customer service, call 877-467-4289

(U.S. and Canada) or 01-800-926-3000 (Mexico)

[www.insigniaproducts.com](http://www.insigniaproducts.com)

INSIGNIA is a trademark of Best Buy and its affiliated companies  
Distributed by Best Buy Purchasing, LLC  
7601 Penn Ave South, Richfield, MN 55423 U.S.A.  
©2020 Best Buy. All rights reserved.