

Read this instruction carefully. See hardware and furniture part list for guidance.  
 Be sure all parts are complete before assembly. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.  
 Follow the figure to start assembling.

**CAUTION :** 1. Do not FULLY - TIGHTEN the nuts or nut bolts until they are ready for assembly.  
 2. Do not OVER - TIGHTEN the nuts or bolts to avoid causing damages to the thread.  
 3. Keep all hardware parts out of reach of children.


**NOTE :** THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tools needed : Screwdriver (not provided).

PART LIST		
ITEM	DESCRIPTION	QTY
A	SEAT	1 PC
B	LEG	2 PCS
C	LEG SUPPORT	2 PCS




HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 x 20mm	4 PCS
2	M6 FLAT WASHER	4 PCS
3	M6 SPRING WASHER	4 PCS
4	WOOD SCREW M4 x 38mm	4 PCS
5	M4 ALLEN KEY (BALL SHAPE)	1 PC

## STEP 1






# ASSEMBLY INSTRUCTIONS



STEP 2



STEP 2





## STEP 4



## STEP 5

**INSTRUCTIONS FOR ADJUSTING LEVELER :**  
**POSITION THE CHAIR IN YOUR SPACE AND LOCATE THE**  
**LEVELER UNDER EACH LEG. TURN THE**  
**LEVELER COUNTER-CLOCKWISE TO EXTEND THE**  
**LEVELER AND CLOCKWISE TO RETRACT IT.**



STEP 6

