











EAT•N




1




2






3




BC350RNC (AG-075F)
BC600RNC (AG-0760)




BC850RNC (AG-0761)




4



5



6




7



OR


8



Brightlayer
Point & Click Setup
Device GUID:
XXXXXXXX-XXXX-XXXX-
XXXX-XXXXXXXXXXXX
brightlayer-remote-monitoring.eaton.com

8

brightlayer-remote-monitoring.eaton.com



5

6

4



EAT•N


Tripp Lite Series UPS Systems

TRIPP LITE
SERIES

tripplite.eaton.com

BC350RNC (AG-075F)
BC600RNC (AG-0760)
BC850RNC (AG-0761)

Quick Start



? For more information:



BC350RNC (AG-075F)



BC600RNC (AG-0760)



BC850RNC (AG-0761)