


VIZIO Home Theater Sound System with Dolby Atmos Setup Options


Scenario 1: Playing content with a Blu-Ray Player or Game Console

- Source device must be playing Dolby Atmos supported content.
- TV and sound bar must be connected via HDMI ARC port. To watch video from the connected source, the TV input should be set to the corresponding HDMI ARC input. CEC should be enabled on the TV and the audio format should be set to Bitstream*.





Scenario 2: Streaming content using a Streaming Stick (Roku, Chromecast, etc.)

- Source device must be playing Dolby Atmos supported content.
- TV and sound bar must be connected via HDMI ARC port. CEC should be enabled on the TV and the audio format should be set to Bitstream*.




Scenario 3: Streaming via Smart TV


- TV apps must support Dolby Atmos content.
- TV and sound bar must be connected via HDMI ARC port. CEC should be enabled on the TV and the audio format should be set to Bitstream*.



✓ Always use HDMI ARC and HDMI 2.0 Cables



✓ Make sure your apps support Dolby Atmos




✓ Make sure your content supports Dolby Atmos

VIZIO Système audio cinéma maison avec options de configuration Dolby Atmos


Scénario 1 : Lire un contenu à l'aide d'un lecteur Blu-Ray ou une console de jeux

- L'appareil source doit lire le contenu Dolby Atmos pris en charge.
- Le téléviseur et la barre de son doivent être connectés au port HDMI ARC. Pour regarder la vidéo à partir de la source connectée, l'entrée du téléviseur doit être réglée sur l'entrée HDMI ARC correspondante. La fonction CEC doit être activée sur le téléviseur et le format audio doit être réglé sur Bitstream*.



Scénario 2 : Lecture en continu à l'aide d'un appareil à lecture continu (Roku, Chromcast, etc.)

- L'appareil source doit lire le contenu Dolby Atmos pris en charge.
- Le téléviseur et la barre de son doivent être connectés au port HDMI ARC. La fonction CEC doit être activée sur le téléviseur et le format audio doit être réglé sur Bitstream*.



Scénario 3 : Lecture en continu via un TV intelligente

- Les applications TV doivent être compatibles avec le contenu Atmos
- Le téléviseur et la barre de son doivent être connectés au port HDMI ARC. La fonction CEC doit être activée sur le téléviseur et le format audio doit être réglé sur Bitstream*.

