

QUICK SETUP GUIDE

Bluetooth Headset


NS-CAHBTEB01 / NSCAHBTEB01-B / NSCAHBTEB01-C / NS-CAHBTEB01-B-C

PACKAGE CONTENTS

- Bluetooth Headset
- USB charging cable
- Earbuds (small and large)
- Quick Setup Guide

FEATURES

- High-quality stereo sound from Bluetooth 4.0 enabled devices
- Battery lasts 12 hours (talk), 10 hours (music)
- Inline controls easily adjust audio
- Curved design fits comfortably around the neck




Before using your new product, please read these instructions to prevent any damage.

CHARGING YOUR HEADSET

A tone sounds (every 60 seconds) and the LED flashes red when your headset battery is low.


- Set power switch to **OFF** before charging.
- Connect the USB charging cable from your headset's charging port to a USB port.



PAIRING YOUR HEADSET

Pairing your first Bluetooth device

- 1 Slide the power switch to **ON**. The LED blinks red and blue and the headset enters pairing mode.



- 2 Make sure that your Bluetooth device is within 33 ft. (10 m) of your headset.
- 3 Turn on your Bluetooth device, turn on Bluetooth, then set your device to pairing mode. For more information, see the documentation that came with your Bluetooth device.
- 4 On your Bluetooth device, select **NS-CAHBTEB01**. The LED lights blue and a tone sounds when your headset pairs to your Bluetooth device.

Manually pairing your Bluetooth device

- 1 Press and hold **Ⓜ** (call) to enter pairing mode. The LED blinks red and blue.
- 2 Make sure that your Bluetooth device is within 33 ft. (10 m) of your headset.
- 3 Turn on your Bluetooth device, turn on Bluetooth, then set your device to pairing mode. For more information, see the documentation that came with your Bluetooth device.
- 4 On your Bluetooth device, select **NS-CAHBTEB01**. The LED lights blue and a tone sounds when your headset pairs to your Bluetooth device.

Pairing two devices

- 1 Pair your headset to your secondary Bluetooth device first. See "Pairing your first Bluetooth device" for instructions.
- 2 Press and hold **Ⓜ** (call) on your Bluetooth headset to enter pairing mode.
- 3 Connect your primary Bluetooth device to your Bluetooth headset. See "Manually pairing your Bluetooth device" for instructions.
- 4 Re-pair your secondary Bluetooth device to your Bluetooth headset. See "Manually pairing your Bluetooth device" for instructions.

Note: When connected to two phones, the headset calling functions will work with the primary phone.

Disconnecting and reconnecting your paired device

Your headset remembers up to six Bluetooth devices and will turn off after three minutes if it is not paired to a Bluetooth device.

TO DISCONNECT...	TO RECONNECT...
Turn off your headset	Turn on your headset. Your headset searches for the last connected Bluetooth device and reconnects.

TO DISCONNECT...	TO RECONNECT...
Move the Bluetooth device out of range	Make sure your Bluetooth device is within 33 feet of your headset.
Turn off your Bluetooth device	Turn on your Bluetooth device, then make sure Bluetooth is on.
Turn off Bluetooth on your Bluetooth device	Turn on Bluetooth on your Bluetooth device.
Connect your Bluetooth device to another Bluetooth device	Disconnect your Bluetooth device from the other Bluetooth device, then set your device to pairing mode. Select "NS-CAHBTEB01" on your Bluetooth device.

Note: If a device does not automatically reconnect, you may need to reselect "NS-CAHBTEB01" on your Bluetooth device.

WEARING YOUR HEADSET



USING YOUR HEADSET

Making phone calls

Note: When your headset is connected to two Bluetooth devices, calling functions work with the primary Bluetooth device (the one that is connected second or made the last outgoing call).

- To make a call, use your phone's controls, then select the headset as the audio source.
- To redial the last number on your primary phone, press **Ⓜ** (call) twice.
- To answer an incoming call, press **Ⓜ** (call).

Note: Your headset vibrates when there is an incoming call.

- To switch audio between your headset and phone, use your phone's controls.
- To reject an incoming call, press and hold **Ⓜ** (call) for two seconds.
- To end a call, press **Ⓜ** (call) one time.

Call waiting

- To switch to an incoming call, press **Ⓜ** (call) twice while speaking on an active call.
- To switch between two active calls, press **Ⓜ** (call) twice.
- To end both calls, press **Ⓜ** (call).

Begin playback on your Bluetooth device.

- To play audio, press **▶||**.
- To skip to the next track, press **▶**.
- To skip to the previous track, press **◀**.
- To fast forward, press and hold **▶**.
- To rewind, press and hold **◀**.

SPECIFICATIONS

- Average charging time: 1.5 - 2 hours
- Operating time: Talk - 12 hours / Music - 10 hours
- Working distance: Up to 33 ft. (10 m)
- Battery: Lithium 200mAh/3.7V

SAFETY INFORMATION/CAUTION

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

TROUBLESHOOTING

PROBLEM	SOLUTION
No sound or low volume	<ul style="list-style-type: none"> Make sure that your Bluetooth device is turned on, Bluetooth is turned on, and "NS-CAHBTEB01" is selected. Turn up the volume on your headset and Bluetooth device. Make sure that your Bluetooth device is not muted. Make sure that your headset and Bluetooth device are not paired to other devices.
Cannot connect with Bluetooth	<ul style="list-style-type: none"> Shorten the distance between your headset and Bluetooth device. Turn your devices off, then on. Re-pair your headset and Bluetooth device. Make sure that your headset and Bluetooth device are not paired to other devices. Make sure that your Bluetooth device supports the HSP, SFP, A2DP, or AVRCP Bluetooth protocol. Make sure that you have selected "NS-CAHBTEB01" on your Bluetooth device.
Bluetooth device keeps unpairing	<ul style="list-style-type: none"> Shorten the distance between your headset and your Bluetooth device. Recharge your headset and Bluetooth device's batteries.
"NS-CAHBTEB01" does not appear on my Bluetooth device	<ul style="list-style-type: none"> Shorten the distance between your headset and Bluetooth device. Put your headset into pairing mode, then refresh your list of Bluetooth devices. For more information, see the documentation that came with your Bluetooth device.
No Power	<ul style="list-style-type: none"> Make sure your Bluetooth headset is charged. Make sure your Bluetooth headset is turned ON.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Compliance IC Statement

This device complies with Industry Canada's licence exempt RSSs. Operation is subject to the following two conditions:
 (1) This device may not cause interference; and
 (2) This device must accept any interference, including interference that may cause undesired operation of the device.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

1-877-467-4289 (U.S. and Canada)
 01-800-926-3000 (Mexico)
www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies
 Distributed by Best Buy Purchasing, LLC
 7601 Penn Ave South, Richfield, MN 55423 U.S.A.
 ©2016 Best Buy. All rights reserved.
Made in China