

## Aura User Manual


### Welcome to the Aura Experience

Thank you for choosing Chamelo's Prismatic Collection, the world's first sunglasses with instantly adjustable color lenses. Aura is designed to seamlessly integrate into your lifestyle, offering both style and function. With Aura, you can change the color of your lenses to reflect your mood, enhance your outfit, or adjust to different lighting conditions with just a simple tap. Whether you're looking to make a fashion statement or enhance your visual experience, Aura has you covered.

Please make sure to register your product at [register.chamelo.com](http://register.chamelo.com) and feel free to reach out to us at any time at [hello@chamelo.com](mailto:hello@chamelo.com).

### Quick Tips for Getting Started with Aura

- Charge Before Use: To ensure maximum performance, fully charge your Aura glasses before the first use.
- Optimal Charging Conditions: Always charge your Aura glasses within the temperature range of 32°F (0°C) to 95°F (35°C).
- Proper Storage: When not in use, store your Aura glasses in the provided protective pouch to avoid scratches and exposure to elements.



### What's in the Box?

- Aura Sunglasses
- Charging Cable
- Glasses Case
- Glasses Cloth
- Manual

© 2023 Chamelo. All rights reserved.

### Product Specifications

- Frame Material:** High-strength TR-90 and alloy materials for durability and comfort.
- Lens Material:** Advanced flexible LC tinting film paired with impact-resistant nylon.
- Transmittance Range:** Adjustable from 20% to 65% to suit various lighting conditions.
- Battery Life:** Up to 47 hours for tint adjustments on a single charge.
- Charging Time:** Full charge in 1 hour.
- Battery Capacity:** 25 mAh polymer battery.
- Weight:** 1.3 oz (40 grams).
- Size & Fit:** Universally accommodating design fits most face shapes and sizes.

## Charging Your Aura Glasses

- Connect the USB-A end of the provided Pogo Pin charging cable to a power source and attach the magnetic pogo pin to the charging port on the glasses.
- Charging Indicators:
  - **Red Light:** Charging in process
  - **Green Light:** Charging complete
  - **Flashing Red:** Low battery warning
- When charging is complete, disconnect the charger from the device and unplug the charger from the power outlet. Do not charge continuously for more than 12 hours.

## Care and Maintenance

- **Cleaning Your Glasses:** Use the included microfiber cloth to gently clean the lenses. Avoid using abrasive materials that could scratch the lens surface. For a deeper clean, use a cloth moistened with water, then dry them with a dry cloth. Be gentle and wipe in the same direction—avoid rubbing in circles or back and forth.

- **Storing Your Glasses:** To maintain the integrity of your glasses, store them in the provided pouch, particularly when traveling or not in use for extended periods.

## Safety Warnings and Precautions

- **General Precautions:** Do not dismantle, repair, or modify the product for any reason.
- **Liquid Exposure:** Do not wet the product directly with liquids, soak it in liquids, or expose it to chemicals.
- **Sun Exposure:** Do not leave the glasses in the sun for extended periods.
- **Tint Adjustment Caution:** Do not attempt to adjust the tint of your lenses while driving or operating machinery.
- **Handling the Temples:** Do not pull on the hinges or squeeze temples excessively.

## Warranty and Support

- **Coverage:** Your Aura glasses come with a 1-year limited warranty covering any defects in materials or workmanship under normal use conditions.

- **Warranty Limitations:** The warranty does not cover damages resulting from improper use, accidents, or unauthorized alterations.

Thank you for purchasing Aura. Your satisfaction is important to us, and we are here to support you. For any assistance, please contact our customer service team at [hello@chamelo.com](mailto:hello@chamelo.com).

Chamelo Eyewear