

# Recliner Assembly Instructions

Your recliner comes packaged in one box.

**DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.**

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.

Estimated Assembly  
Time in Minutes

★ ★ ★  
<15 <45 60+




## Parts List

**A** 1 x Back



**B** 1 x Seat



\* **C** 2 x Front Legs



\* **D** 2 x Back Legs



\* **E** 4 x Plastic Washers




\* Replaceable Parts




legs can be found  
under the seat.

## Assembly


### Step 1




### Step 2



### Step 3



### Step 4



Your recliner style may differ from images. Care for your furniture by periodically tightening all legs.

#### About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

**CAUTION:** Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531

Mon-Fri 8:00am - 4:30pm CST

customerservice@furniturequestions.com